

83 N17556

EIGENSPACE TECHNIQUES FOR ACTIVE FLUTTER SUPPRESSION
FINAL REPORT COVERING THE PERIOD OCT. 1981 TO DEC. 1982
NASA RESEARCH GRANT NAG-1-217*

William L. Garrard (Principal Investigator)
Bradley S. Liebst

Department of Aerospace Engineering and Mechanics
University of Minnesota
Minneapolis MN 55455



*NASA Technical Officer for this grant was Mr. William M. Adams, Jr.
of NASA Langley Research Center, Hampton VA 23665

Abstract

Eigenspace (ES) techniques are used to design an active flutter suppression system for the DAST ARW-2 flight test vehicle. The ES controller meets control surface activity specifications and at the flutter test condition provides reduced wing root torsion at the gust test condition, and results in improved flutter boundaries. The ES controller is compared with a controller designed using Linear Quadratic (LQ) techniques. The LQ controller exhibits better phase margins at the flutter condition than does the ES controller but the LQ design requires large feedback gains on actuator states while the ES does not. This results in reduced overall actuator gain for the LQ design.

Nomenclature

Vectors

u = control input

v_i = attainable closed loop eigenvector associated with λ_i eigenvalue

v_{d_i} = desired closed loop eigenvector associated with λ_i eigenvalue

w_i = vector used in calculation of ES gain matrix, see Eqn. 17

x = system state

ξ_F = flexure modal displacements

ξ_C = control surface displacements

Γ = disturbance input vector

Matrices

$[A_m]$ = aerodynamic coefficient matrix
 A = dynamics matrix
 B = control distribution matrix
 $[C_s]$ = structural damping matrix
 E = aerodynamic coefficient error matrix
 K = control gain matrix
 $[K_s]$ = structural stiffness matrix
 $[M_s]$ = structural mass matrix
 P_i = eigenvector weighting matrix
 Q = state weighting matrix
 $[Q_c]$ = calculated unsteady aerodynamic influence coefficient matrix
 $[Q_A]$ = s-plane representation of unsteady aerodynamic influence coefficient matrix
 R = control weighting matrix
 V = matrix whose columns are v_i
 W = matrix whose columns are w_i
 Λ = diagonal matrix composed of λ_i

Scalars

c = reference chord, 0.75m
 $H(s)G(s)$ = loop transfer function
 j = $\sqrt{-1}$
 k = reduced frequency
 L = reference length in gust model, 762m
 M = Mach number
 q = dynamic pressure
 s = Laplace operator
 V = forward velocity
 β_m = aerodynamic lag frequencies
 η = zero mean white noise input to gust model with intensity,

$$\frac{L}{V} \overline{\xi_G^2}$$
 λ_i = i th eigenvector
 $\overline{\sigma}(E)$ = maximum singular value of E
 $\underline{\sigma}(E)$ = minimum singular value of E
 ω = circular frequency
 ξ_G = normal wind gust velocity
 $\overline{\xi_G}$ = rms normal wind gust velocity

Subscripts

i = inboard aileron
o = outboard aileron
ES = eigenspace
LQ = linear quadratic
s = structural

Superscripts

* = complex transpose
T = transpose
-1 = inverse

Table of Contents

I.	Introduction.	6
II.	Mathematical Models and Performance Specifications	8
III.	Eigenspace Design	19
IV.	Results	29
V.	Conclusions	43
VI.	References.	47
VII.	Publications Issued During the Course of this Research.	49

Appendices

A. Flexure Mode Shapes

B. Program Descriptions and Listings

List of Tables

Table 1	Maximum Singular Value of Error Matrix vs β
Table 2	Eigenvalues of DAST ARW-2 Flight Test Vehicle at M=0.86, h=4572m, Based on 2 Rigid Body and 7 Flexure Modes
Table 3	Eigenvalues of DAST ARW-2 Flight Test Vehicle at M=0.86, h=4572m, Based on 3 Flexure Modes
Table 4	Comparison of RMS Control Surface Activity for Various Controller Designs and Flight Conditions
Table 5	RMS Response for Various Weights on Actu- ator Rates
Table 6	RMS Loads at Gust Test Condition

List of Figures

- Fig. 1 Root Locus of Seven Mode Model of Uncontrolled Wing as Velocity is Varied
- Fig. 2 Root Locus of Three Mode Model of Uncontrolled Wing as Velocity is Varied
- Fig. 3 Variation in Actuator Roots with Weighting on Inboard Aileron Deflection Rate
- Fig. 4 Inboard Actuator Transfer Function Frequency Response
- Fig. 5 Root Locus of LQ Controlled Wing as Velocity is Varied
- Fig. 6 Root Locus of ES Controlled Wing as Velocity is Varied
- Fig. 7 Flutter Boundaries for Uncontrolled, LQ, and ES Controlled Wing
- Fig. 8 Frequency Response of Magnitude of $H(s)G(s)$ for LQ and ES Designs
- Fig. 9 Frequency Response of Phase of $H(s)G(s)$ for LQ and ES Designs

Eigenspace Techniques for Active Flutter Suppression

I. Introduction

The objective of the research described in this report is the application of Eigenspace (ES) design techniques to the synthesis of active flutter suppression systems. ES techniques allow the designer to use feedback control to place closed loop eigenvalues and shape closed loop eigenvectors to satisfy performance specifications. The basic theory behind ES design has been given by Moore [1] and others. Moore has shown that it is possible not only to place controllable eigenvalues and shape controllable eigenvectors but also to shape uncontrollable eigenvectors. Since the dynamic response characteristics of a system are determined by its eigenvectors as well as its eigenvalues, the ability to shape eigenvectors provides the designer with an important tool.

If performance specifications are given or can be interpreted in terms of desired closed loop eigenvalues and eigenvectors, ES techniques provide a natural design procedure where the desired eigenstructure (if obtainable) can be calculated directly without iteration. Cunningham [2] has shown how ES techniques can be used to improve aircraft flying qualities by placing rigid body poles in desired locations and decoupling rigid body modes. If performance specifications cannot be stated directly in terms of closed loop eigenvalues and eigenvectors, for

example specifications on rms responses or stability margins, the application of ES techniques is not so straightforward.

This is the case in aeroelastic control problems such as flutter suppression. One of the principal contributions of this report is the description of a methodology for application of ES techniques to active flutter suppression and other aeroelastic control problems.

To the authors' knowledge, the full power of ES techniques to shape eigenvectors as well as place eigenvalues has not been applied to active flutter suppression. Ostroff and Pines [3] used eigenvalue placement to design a flutter controller, but did not attempt to shape closed loop eigenvectors. In this report ES design techniques are applied to the design of a flutter suppression system for the DAST ARW-2 flight test vehicle. Only full-state feedback is considered. Use of ES techniques in the design of robust state observers will be the subject of future investigations.

It is shown that ES techniques can easily be used to design a flutter controller which satisfies performance specifications on rms control surface activity at the design condition. This controller also provides some gust load alleviation capability at off-nominal conditions. The ES controller requires no feedback on control surface actuator states and thus the open loop frequency response characteristics of the actuators are retained in the closed loop system.

The remainder of the report is divided into four major sections. First mathematical models of the aircraft, actuators, and normal wind gust are presented and performance requirements are discussed. Next the theory of ES design is described. Then the results obtained by applying this theory to the design of a flutter suppression system for the DAST ARW-2 aircraft are given and compared with results obtained from a controller designed using Linear Quadratic (LQ) optimal control theory. Finally conclusions and suggestions for future research are presented. A brief description and listing of a computer program used to perform ES design is given in Appendix B.

II. Mathematical Models and Performance Requirements

The DAST ARW-2 flight test vehicle is a Firebee II Drone which has been modified by replacing the conventional wing with a high aspect ratio, supercritical wing designed to flutter within the flight envelope. Two control surfaces, an inboard and an outboard aileron, are available on the wing and a stabilizer is available on the horizontal tail. The outboard aileron is to be used for flutter suppression, gust load alleviation, and maneuver load alleviation. The inboard aileron is to be used for maneuver load alleviation, and the stabilizer is to be used to compensate for reduced static stability, for automatic flight control, gust load alleviation, and maneuver load alleviation. In practice only the outboard aileron

is to be used for flutter control. However, both the inboard and outboard surfaces were utilized in the controller designs since ES design methodologies are most useful in the design of controllers for systems with multiple control inputs.

The design flight condition for the flutter control system was a Mach Number of 0.86 and an altitude of 4572 m (15000 ft). At this flight condition the flutter control system was required to stabilize the wing. A normal gust with rms velocity of 3.66 m/s (12 ft/s) was assumed at this condition. The rms deflection of the inboard aileron was limited to 10° and the deflection rate to $130^\circ/\text{s}$. The rms deflection of the outboard aileron was limited to 15° and the deflection rate to $740^\circ/\text{sec}$. The control system was also to be evaluated on its ability to reduce bending and torsional stresses and shear forces in the wing at a gust test condition of Mach 0.7 and 4572 m. The vertical gust velocity at this condition was 18 m/s (59 ft/s). In the actual DAST vehicle, the flutter suppression system would not be used at this condition because a separate gust load alleviation system is available. However, the gust test condition did provide a convenient condition for evaluating the performance of the flutter controllers at an off-nominal condition; therefore, in this study it was assumed that the flutter controller was also to be used for gust load alleviation.

Actuator/Control Surfaces

Stabilizer. The stabilizer transfer function was a simple first-order lag

$$\xi_{c_e} / u_e = \frac{20}{s+20} \quad (1)$$

The allowable rms control surface activity levels for the stabilizer were 7 degrees and 80 degrees/s.

Inboard Aileron. An eleventh-order transfer function with third order numerator dynamics was given for the inboard aileron. Up to about 300 rad/s, a fourth order model gave an acceptable approximation of the eleventh order inboard aileron transfer function. This fourth order approximation was

$$\xi_{c_i} / u_i = 1.614 \times 10^{11} / (s^2 + 671s + (477)^2) (s^2 + 322s + (878)^2) \quad (2)$$

Outboard Aileron. A seventh-order transfer function with second-order numerator dynamics was given for the inboard aileron. Up to about 300 rad/s, a third order transfer function gave an acceptable approximation of the seventh order outboard aileron transfer function. This third order approximation was

$$\xi_{c_o} / u_o = 1.774 \times 10^7 / (s+180) (s^2 + 251s + (314)^2) \quad (3)$$

Wind Gust. The wind gust was modeled by the second-order model given below

$$\xi_G / \eta(s) = (1 + (\sqrt{3}L/V)s) / (1 + (L/V)s)^2 \quad (4)$$

Aircraft. The modes of the aircraft considered were rigid body plunge and pitch modes and seven symmetric aeroelastic modes of the wing. The flexible aircraft model was

$$([M_s]s^2 + [C_s]s + [K_s]) [\xi_F] + q[Q_c(s)] \begin{bmatrix} \xi_F \\ \xi_c \\ \xi_G \\ \frac{\xi_G}{V} \end{bmatrix} = 0 \quad (5)$$

The aerodynamic influence matrix $[Q_c(s)]$ was calculated over a range of reduced frequencies ranging from 0.0 to 1.2 by a doublet lattice procedure. A rational s-plane approximation of $Q_c(s)$ was given by the approximation

$$[Q_A(s)] = [A_0] + [A_1] \frac{cs}{2V} + [A_2] \left[\frac{cs}{2V} \right]^2 + \sum_{m=1}^L \frac{[A_{m+2}]s}{s + \frac{2V}{c}\beta_m}$$

This approximation has been widely used in design of active flutter suppression systems [4-10].

The first column of the matrix $[A_0]$ was set equal to the first column of $[Q_c(0)]$, which is zero since the aerodynamic forces due to plunge displacement are zero. The second column of $[A_0]$ gives the force due to a change in angle of attack resulting from a change in pitch angle and must be set equal to the second column of $[Q_c(0)]$. The first column of $[A_1]$ multiplied by $c/2$ gives the force due to a change in plunge velocity. Since the force due to a change in angle of attack must be the same regardless of whether this change results from a change in plunge velocity or a change in pitch angle, the first column of

$[A_1]$ must equal the second column of $[Q_c(0)]$ divided by $c/2$ (there is also a scaling factor of 0.0062486 which must be divided into $[Q_c(0)]$).

Usual procedure is to select the β'_m 's so as to bracket the reduced flutter frequencies [6]. Once the β'_m 's are specified, the remaining elements of the $[A_m]$ matrices are determined to give the best least squares fit to Q_c over the range of reduced frequencies for which this matrix has been calculated.

In this study a new method was used to select the β'_m 's. An error matrix was defined as

$$E(j\omega) = [Q_c(j\omega)] - [Q_A(j\omega)]$$

The norm of this matrix can be bounded above and below by its maximum and minimum singular values [11]

$$\underline{\sigma}(E) \leq \frac{\|Ex\|}{\|x\|} \leq \overline{\sigma}(E)$$

The singular values of E are defined as the positive square roots of the eigenvalues of E^*E . If the β'_m 's are chose to minimize $\overline{\sigma}(E)$, the norm of the error matrix will be small. In this study a single β was used in $[Q_A]$. Since the reduced flutter frequency was known to be small (0.15), β was selected to minimize $\overline{\sigma}(E)$ at zero frequency. The procedure for determining the $[A_m]$'s and β was as follows (1) a small initial value for β was arbitrarily selected, (2) the first column of $[A_0]$ was set equal to zero, the second column of $[A_0]$ was set equal to the second column of $[Q_c(0)]$ and the first column of $[A_1]$ was set equal to the second column of $[Q_c(0)]$ divided by $c/2$ times a scale factor, (3) the remaining values of $[A_0]$, $[A_1]$, $[A_2]$ and $[A_3]$ were determined to give the

best least squares fit to $[Q_c(j2kV/c)]$ over the range of reduced frequencies 0.0, 0.05, 0.2, 0.3, 0.3, 0.4, 0.5, 0.6, 0.7, 0.8, 1.0 and 1.2 (4) the maximum singular value of the error matrix $E(j\omega=0)$ was calculated (5) β was increased by a small amount and the process was repeated until $\bar{\sigma}(E)$ reached a minimum. The results are summarized below

β	$\bar{\sigma}(E(0))$
0.100	214.4
0.125	138.2
0.130	137.0
0.135	147.0
0.150	162.8

Table 1 Singular Value of Error Matrix versus β
The value of β equal to 0.13 which minimizes $\bar{\sigma}(E(0))$ is very close to the reduced flutter frequency of 0.15. The eigenvalues resulting from this model for a Mach number of 0.86 and an altitude of 4572 m are given below

Mode	Eigenvalues
plunge	0, -1.17
pitch	-1.74±j6.29
1st flexure	41.6±j118.1
3rd flexure	-0.7±j136.6
4th flexure	-97.1±j108.4
6th flexure	-16.9±j218.3
8th flexure	-4.1±j397.4
9th flexure	-11.0±j425.0
10th flexure	-24.8±j452.5

Table 2 Eigenvalues of DAST ARW-2 Flight Test Vehicle at $M=0.86$, $h=4572m$ based on 2-Rigid Body and 7 Flexure Modes

The values of the flexure mode eigenvalues are close to those calculated for the ARW-2 using a model containing four lag states [12]. The pitch eigenvalues were not too different from the actual values of $-1.5 \pm j5.6$; however, one of the plunge eigenvalues is considerably different from the actual values of $0.0 \pm j1.1 \times 10^{-3}$. The flutter characteristics of the aircraft are not affected by the rigid body modes and these modes are not included in the model used in the control system design. The poorest correlation between elements of the $[Q_C]$ and $[Q_A]$ matrices occurred for the coefficients associated with the gust velocity, even then rms structural and control surface gust responses calculated using the model with a single β were close to those calculated from higher-order models using several values of β_m .

It is felt that selection of the numerical values of the β'_m 's based on the maximum and minimum singular values of an error matrix such as given by Eq. 7 has considerable potential in generating low-order approximate models of unsteady aerodynamics. Even the simple approach of minimizing the maximum singular value of the error matrix at a fixed frequency yielded acceptable results. Other approaches such as choosing the β'_m 's to minimize functions of both the maximum and minimum singular values over a range of frequencies should be investigated.




Fig. 1 Root Locus of Seven Mode Model of Uncontrolled Wing as Velocity is Varied

Some possible indices are as follows:

1. Minimize average $\bar{\sigma}$ and $\underline{\sigma}$ over a range of frequencies, i.e.

$$\min\left\{\frac{1}{\omega_2 - \omega_1} \int_{\omega_1}^{\omega_2} \sigma(E)(j\omega) d\omega\right\}$$

2. Minimize maximum value of $\bar{\sigma}$ and $\underline{\sigma}$ over a range of frequencies, i.e.

$$\min\{\max(\sigma(E(j\omega)))\} \quad \omega_1 \leq \omega \leq \omega_2$$

3. Minimize weighted sum of $\bar{\sigma}$ and $\underline{\sigma}$ over a range of frequencies, i.e.

$$\min\left\{\sum_{i=1}^N a_i \sigma(E(j\omega_i))\right\}$$

An examination of the 10 flexure modes (see Appendix A) indicated that modes 2 and 5 were primarily fuselage bending modes and mode 7 was exclusively a tail mode. Therefore these three modes were not considered further in the analysis. Mode 1 was primarily the first wing bending mode, mode 2 was the second wing bending mode, and mode 6 was the first wing torsion mode. These modes were obviously important in modeling flutter and were retained. Modes 3 and 8 included wing tip bending and it was felt that these modes should also be analyzed further. Mode 9 was primarily wing bending and mode 10 was primarily wing torsion and these modes were also retained. Thus seven flexure modes, the 1st, 3rd, 4th, 6th, 8th, 9th and 10th were included in the initial flutter analysis. The loci of the eigenvalues of these modes as velocity was varied are shown in Fig. 1. The first mode flutters at a velocity of about

241 m/s (M=0.75) at a frequency of 120 rad/s. Modes 3 and 8 are insensitive to changes in velocity indicating that they are primarily vibrational modes; however, modes 9 and 10 do vary somewhat with velocity. Eigenvalues were calculated using models in which various modes were deleted. Deletion of the 3rd, 8th, 9th and 10th modes has very little affect on the lower modes.

3 Mode Model	
Mode No	Eigenvalue
6	-15.7±j216.1
4	-94.3±j106.4
1	+39.9±j118.0

Table 3 Eigenvalues of DAST ARW-2 Flight Test Vehicle at M=0.86 h=4572m Based on 3 Flexure Modes.

Basic flutter characteristics could be accurately modeled with only three modes corresponding to the first and second bending (modes 1 and 4) and first torsion (mode 6), and computational expense could be reduced significantly by reducing the order of the system model; therefore, the design studies were based on a structural model containing only these three flexure modes. The loci of the eigenvalues of the three mode model as velocity is varied are shown in Fig. 2.

Equations 2-6 can be combined to give the equations which describe the wing, control surfaces and actuators, and wind gust in vector-matrix form as

$$\dot{\mathbf{x}} = \mathbf{Ax} + \mathbf{Bu} + \mathbf{\Gamma}\eta \quad (8)$$

The 18th order state vector, \mathbf{x} , consists of (1) the dis-




Fig. 2 Root Locus of Three Mode Model of Uncontrolled Wing as Velocity is Varied

placements and velocities associated with the three flexure modes, (2) the unsteady aerodynamic lag states, (3) the states associated with the inboard and outboard control surfaces, and (4) the states associated with the wind gust model. The 2nd order control vector, u , consists of the inputs to the inboard and outboard aileron/actuators and the zero mean white noise input, η , drives the wind gust model. (See Appendix B for a more detailed discussion of Eq. 8)

III. Eigenspace Design

Theory

Moore [1] and others have shown how feedback can be used to directly place eigenvalues and also shape eigenvectors. If performance specifications are given or can be interpreted in terms of desired closed loop eigenvalues and eigenvectors, then ES techniques can provide a natural design procedure. If performance specifications cannot be clearly stated in terms of closed loop eigenvalues and eigenvectors, for example specifications on rms responses, it may be necessary to iterate eigenvalues and eigenvectors until performance specifications are met.

Before discussing the details of the ES flutter controller, the theoretical basis of ES design methodology will be discussed. Consider a system modeled in state variable form as

$$\dot{x} = Ax + Bu + \Gamma\eta$$

with measurements

$$y = Cx$$

where the state $x \in \mathbb{R}^n$, the feedback control $u \in \mathbb{R}^m$, and the output $y \in \mathbb{R}^p$. If we express u in output feedback form

$$u = Ky = KCx$$

the the closed loop system response is

$$\dot{x} = (A + BKC)x + \Gamma\eta \quad (9)$$

The ES design procedure consists, of determining a gain matrix, K , such that for all desired closed loop eigenvalue (λ_i) and eigenvector (v_i) pairs

$$(A + BKC)v_i = \lambda_i v_i \quad (10)$$

Introduce $w \in \mathbb{R}^m$ where

$$w_i = KCv_i \quad (11)$$

The problem becomes one of determining w_i such that

$$(\lambda_i I - A)v_i = Bw_i$$

where K is determined from Eq. 11.

Case 1: Full State Feedback

If all the states of the system are available, the feedback control law becomes (assuming $p=n$ and letting $C=I$ without loss in generality)

$$u = Kx$$

The design problem is to find w_i and K such that

$$(\lambda_i I - A)v_i = Bw_i \quad (12)$$

and

$$w_i = Kv_i \quad (13)$$

For the entire collection of closed loop eigenvalues and eigenvectors Eq. (12) becomes

$$V\Lambda - AV = BW \quad (14)$$

Likewise from Eq. (13)

$$W = KV \quad (15)$$

therefore

$$K = WV^{-1} \quad (16)$$

Case 2: Output Feedback ($p < n$)

$$y = Cx$$

In this case Eq. (15) becomes

$$W = KCV$$

Since C is of rank $p < n$ a unique solution for K is impossible.

The alternative is to place only p eigenvalue-eigenvector pairs, i.e. choose p λ_i 's and the corresponding p columns of V and solve for K such that

$$K = W(CV)^{-1}$$

The key design issue is to find W which satisfies Eq. (14).

In general one cannot completely satisfy both exact eigenvalue and eigenvector placement.

Case 3: Single Input Systems

For single inputs Eq. (12) reduces to

$$(\lambda_i I - A)v_i = bw_i$$

where w_i is a scalar. This single variable cannot be adjusted to place n parameters on the left hand side, therefore, the single input case only involves pole placement with arbitrary eigenvector position. The gain K is unique in this case.

Case 4: Multiple Input Systems

The real benefit of eigenspace techniques is realized when more than one control is available. If the rank of B

is n , i.e., one independent control for each state then from Eq. (12)

$$w_i = B^{-1}(\lambda_i I - A)v_i$$

for each desired λ_i and v_i of the closed loop system.

Practically speaking, however, one has fewer controls than states and exact placement of λ_i and v_i for all $i=1,2,\dots,n$ is impossible. The design procedure then becomes one of choosing portions of v_i to eliminate certain state responses from a mode while emphasizing others and letting other responses react arbitrarily. Assuming the system is controllable and $\text{rank}(B) = m < n$, only m free parameters can be specified. If it is desired to change an eigenvalue associated with a controllable mode, then for the new eigenvalue, λ_i , the matrix $(\lambda_i I - A)$ is nonsingular. Thus

$$v_i = (\lambda_i I - A)^{-1} B w_i \quad (17)$$

or

$$v_i = L_i w_i \quad (18)$$

where

$$L_i = (\lambda_i I - A)^{-1} B$$

Since there are not enough independent controls available to arbitrarily place all λ_i 's and v_i 's, the w_i 's are selected to minimize the following least square performance index

$$J_i = (v_{d_i} - v_i)^* P_i (v_{d_i} - v_i)$$

where P_i is used to emphasize certain components of v_{d_i} .

Solving for w_i which minimizes J_i produces an optimal psuedo-

inverse

$$w_i = (L_i^* P_i L_i)^{-1} L_i^* P_i v_{d_i}$$

and v_i is given by Eq. (18).

If certain eigensolutions are not to be altered (e.g. actuator poles) or if λ_i is uncontrollable then

$$w_i = 0$$

and Eq. (12) is satisfied. The general design procedure used is to vary P_i , λ_i , and v_{d_i} until performance specifications on rms values of the state and control are met.

The above analysis is valid for complex or real eigensolutions. If an entirely real K matrix is desired then the the problem must be decoupled into its real and imaginary parts. If

$$\lambda = \lambda_R + j\lambda_I$$

$$v = v_R + jv_I$$

$$w = w_R + jw_I$$

then for real A

$$(\lambda_i I - A) v_i = B w_i$$

becomes in entirely real terms

$$\begin{bmatrix} (\lambda_R I - A) & -\lambda_I I \\ \lambda_I I & (\lambda_R I - A) \end{bmatrix} \begin{bmatrix} v_R \\ v_I \end{bmatrix} = \begin{bmatrix} B w_R \\ B w_I \end{bmatrix} \quad (19)$$

and

$$\begin{bmatrix} v_R \\ v_I \end{bmatrix} = \begin{bmatrix} (\lambda_R I - A) & -\lambda_I I \\ \lambda_I I & (\lambda_R I - A) \end{bmatrix}^{-1} \begin{bmatrix} B w_R \\ B w_I \end{bmatrix} \quad (20)$$

or

$$\begin{bmatrix} v_R \\ v_I \end{bmatrix} = L \begin{bmatrix} w_R \\ w_I \end{bmatrix}$$

where

$$L = \begin{bmatrix} (\lambda_R I - A) & -\lambda_I I \\ \lambda_I I & (\lambda_R I - A) \end{bmatrix}^{-1} \begin{bmatrix} B & 0 \\ 0 & B \end{bmatrix} \quad (21)$$

Then the optimal psuedo-inverse solution in entirely real terms is

$$w_i = (L_i^T P_i L_i)^{-1} L_i^T P_i v_{d_i} \quad (22)$$

where

$$w_i = \begin{bmatrix} w_{R_i} \\ w_{I_i} \end{bmatrix}$$

$$v_{d_i} = \begin{bmatrix} v_{d_{R_i}} \\ v_{d_{I_i}} \end{bmatrix}$$

$$P_i = \begin{bmatrix} P_{R_i} & 0 \\ 0 & P_{I_i} \end{bmatrix}$$

To determine K with λ_1 and λ_2 complex conjugates, we must solve

$$K[v_{R_1} + jv_{I_1}, v_{R_1} - jv_{I_1}, V] = [w_{R_1} + jw_{I_1}, w_{R_1} - jw_{I_1}, W] \quad (23)$$

where V and W are the remaining v_i 's and w_i 's. Post multiplying both sides of this equation by

$$R = \begin{bmatrix} \frac{1}{2} & -j\frac{1}{2} & 0 \\ \frac{1}{2} & +j\frac{1}{2} & 0 \\ 0 & 0 & I \end{bmatrix} \quad (24)$$

yields

$$K[v_{R_1}, v_{I_1}, V] = [w_{R_1}, w_{I_1}, W] \quad (25)$$

Now the left hand eigenvector matrix is nonsingular so

$$K = [w_{R_1}, w_{I_1}, W][v_{R_1}, v_{I_1}, V]^{-1} \quad (26)$$

This procedure can be applied to any complex conjugate pair. It should be noted, however, that the transformation matrix R is not unique so neither is K .

Application to Active Flutter Suppression

Using the above procedure a flutter control system was designed. The initial ES controller was designed by rotating the unstable eigenvalues around the imaginary axis and leaving all other eigensolutions in their open loop configuration. This resulted in acceptable rms control surface activity at the flutter condition and a stable response at the gust test condition. Although the ES design stabilized the wing at the gust test condition, the maximum allowable values for the rms inboard deflection rate and outboard deflection and deflection rate were exceeded. It was felt that the performance at the gust test case might be enhanced by redesign of the control system. Since the aircraft exhibits satisfactory response at velocities somewhat less than the flutter speed, it was decided to use ES design techniques to force the closed loop eigenvalues at the design velocity (275 m/s) to be the same as the open loop eigenvalues at the velocity of 200 m/s (this is 20% less than the flutter speed) and to force the closed

loop eigenvectors at 275 m/s to approach the open loop eigenvectors at 200 m/s. The control was designed to retain the eigenvalues and eigenvectors associated with the actuators, unsteady aerodynamics, and gust model at their open loop values so that energy would not be transferred to these modes. (The gust states are uncontrollable and the gust eigenvalues cannot, in any case, be moved.) The ability to keep poles in desired locations is one of the key advantages of the ES design.

In the open loop condition, the actuator dynamics are decoupled from the aeroelastic modes; therefore, the components of the aeroelastic eigenvectors in the direction of the actuator states are zero. Thus driving the closed loop aeroelastic eigenvectors to exactly their open loop values would decouple the actuators from the aeroelastic response of the wing. This is obviously not desirable since the wing would be uncontrolled; however, it is possible to reduce control surface activity and still stabilize the wing by using the weighting matrices P_i to penalize large values of the components of the closed loop aeroelastic eigenvectors in the actuator directions. Initially all closed loop aeroelastic eigenvalues at 275 m/s were placed at the locations of the open loop aeroelastic eigenvalues at 200 m/s and the weighting matrices were chosen to be identity matrices. This resulted in a reduction of control surface activity of less than 7% at the gust test condition. The rms inboard aileron deflection rate was still over three

times its allowable value while the outboard aileron deflection and rates were about twice their allowable values. A gust of 5.7 m/s would saturate the inboard control surface while the outboard surface remained unsaturated since its deflection and rate were about two-thirds of the allowable values.

It was decided to shift some of the control effort from the inboard to the outboard aileron in an attempt to increase the gust velocity at which the system would saturate. This was accomplished by increasing the weights on the components of the aeroelastic eigenvectors in the inboard actuator directions while retaining all other weights at one. Values of these weights were increased to 2.5×10^3 yielding the results in Table 4. The inboard rate was reduced substantially without excessively increasing outboard activity. Specifications on inboard rate and outboard deflection and rate were still not met at the gust test condition but all of the quantities were about twice their maximum values. Thus both control surfaces would saturate at about the same gust velocity (8.3 m/s). Since it proved impossible to further reduce outboard surface activity by adjusting the weighting matrices P_i , the ES controller resulting from eigenvector shaping to reduce inboard rate was chosen for further evaluation.

Table 4

Comparison of RMS Control Surface Activity
for Various Controller Designs and Flight Conditions

Controller Design	Inbd Defl (Deg)		Inbd Rate (Deg/s)		Outbd Defl (Deg)		Outbd Rate (Deg/s)	
	Flutter	Gust Test	Flutter	Gust Test	Flutter	Gust Test	Flutter	Gust Test
<i>Unstable Roots Rotated About Imag. Axis</i>								
ES	0.5	5.0	108.0	412.0	3.3	31.4	509.0	1464.0
<i>Unstable Roots Rotated About Imag. Axis</i>								
LQ	1.8	*	271.0	*	2.8	*	407.0	*
<i>Eigenvector shaping to Reduce Inbd Rate (Final ES)</i>								
	0.9	8.1	86.0	279.7	4.7	31.2	612.0	1464.0
<i>Weighting Inbd Rate in Perf Index (Final LQ)</i>								
	0.7	4.6	85.0	284.1	3.1	30.2	486.0	1335.1
<i>Final ES Inbd Failed</i>								
	-	-	-	-	4.4	26.5	572.0	1427.0
<i>Final LQ Inbd Failed</i>								
	-	-	-	-	3.5	30.0	519.0	1410.0
Max Allowable	10.0	10.0	130.0	130.0	15.0	15.0	740.0	740.0

*Unstable

Results

In addition to the ES design, a flutter controller was designed using Linear Quadratic(LQ) optimal control theory. LQ control theory has been discussed extensively in numerous texts, for example Ref. 13. The basic LQ design procedure consists of selecting quadratic weighting matrices Q and R in a scalar performance index

$$J = \frac{1}{2} \int_0^{\infty} [x^T Q x + u^T R u] dt \quad (27)$$

The control which minimizes this performance index is given as

$$u = Kx$$

where K is the solution of a matrix Ricatti equation.

It is well known that if Q is set equal to zero and R equal to the identity matrix in the performance index given by Eq. (27), then all stable eigenvalues will remain unchanged and all unstable eigenvalues will be rotated about the imaginary axis [13]. Initial LQ design was performed using this approach; however, as shown in Table 4, the rms deflection rate for the inboard actuator was approximately double its allowed maximum at the flutter test condition and the controller resulted in an unstable wing at the gust test condition (note the uncontrolled wing is stable at this condition). Since all rms responses except the inboard actuator deflection rate were acceptable at the flutter test condition, only this state was weighted in the performance index. The results of varying the weight on inboard actuator deflection rate is shown in Table


Table 5

RMS Response for Various Weights
on Inboard Actuator Rate

Weight on Inbd Deflection Rate	RMS Response (Degrees and Degrees/s)			
	Inbd Def.	Inbd Rate	Outbd Def.	Outbd Rate
0	1.60	217.6	2.73	427
1×10^{-5}	1.58	256.0	2.74	428
5×10^{-5}	0.92	122.0	3.02	470
1×10^{-4}	0.66	84.8	3.14	486
5×10^{-4}	0.22	26.0	3.32	514
1×10^{-3}	0.12	14.0	3.36	518
Max Allowable	10.0	130.0	15.0	740

5. The rms value of the inboard actuator deflection rate decreases fairly rapidly as its weight is increased and the rms activity level of the outboard control surface does not increase substantially. The eigenvalues associated with the flexure modes and the outboard aileron do not change as the weight on the inboard actuator rate is changed; however, as shown in Fig. 3, the eigenvalues associated with the inboard actuator change radically. The moduli of three of the roots become very large while the fourth root approaches zero. Since any large change in actuator frequency response characteristics would be difficult to obtain without substantially redesigning the actuator, a value for the weight on actuator deflection rate of 1×10^{-4} was selected. This gave acceptable rms responses at the flutter test condition and also stabilized the wing at the gust test condition and did not affect the frequency response of the inboard actuator too much. The open and closed loop inboard actuator frequency response curves for the final design are shown in Fig. 4. It can be seen that the overall gain for the closed loop system is reduced compared with the open loop response. At zero frequency the open loop gain is unity and the closed loop gain is 0.79. Thus the forward loop gain would have to be increased by 21% in order to restore the steady state gain to its open loop value. This might be difficult without modifications to existing actuator hardware.

Fig. 3 Variation in Actuator Roots with Weighting on Inboard Aileron Deflection Rate






Fig. 4 Inboard Actuator Transfer Function Frequency Response

It appears to be impossible to design either an ES or LQ flutter controller which also meets the specification on rms control surface activity at the gust test condition. In the actual DAST ARW-2 vehicle, the inboard aileron is used for maneuver load alleviation but not for flutter suppression or gust load alleviation. Furthermore a different controller design is used for gust load alleviation than for flutter suppression. Thus it is not too surprising that the ES and LQ flutter controllers do not meet specifications on rms surface activity at the gust test condition. However, if the rms gust velocity at the gust condition is reduced to 8.3 m/s (about 50% of its nominal value) both the ES and LQ controllers meet all specifications on rms surface activity. Table 6 shows that both controllers provide some torsional load alleviation at this flight condition. The bending and torsional stresses and shear force were calculated at nine stations on the wing (station 1 is at the root and station 9 is near the tip). The LQ design results in the largest rms bending moments at all stations. The ES design results in bending moments which are lower than those resulting from the LQ design but higher than the uncontrolled values. The differences in bending moment in all three cases are not large. Both the LQ and ES designs result in substantial reductions (over 50%) in torsional stresses at all stations compared with the uncontrolled values. The LQ reduces torsional stresses slightly more than the ES design. The ES design results in lowest values of shear near the wing

Table 6

RMS Loads at Modified Gust Test Condition
(M=.7, h=4572m, $V_G=8.3$ m/s)

		Root			Station				Tip	
		1	2	3	4	5	6	7	8	9
FINAL LQ	<i>Bending Moment (N-M)</i>	5740	4530	3426	2444	1371	889	377	83	5
	<i>Shear (N)</i>	92	82	74	63	42	36	24	6	1
	<i>Torque (N-M)</i>	36	54	73	82	73	63	52	6	2
FINAL ES	<i>Bending Moment (N-M)</i>	5558	4412	3359	2418	1374	900	389	91	5
	<i>Shear (N)</i>	87	79	71	61	42	36	24	6	1
	<i>Torque (N-M)</i>	46	63	79	85	76	65	53	7	1
OPEN LOOP	<i>Bending Moment (N-M)</i>	5545	4262	3116	2125	1115	671	248	47	3
	<i>Shear (N)</i>	98	85	75	61	38	31	18	3	1
	<i>Torque (N-M)</i>	106	130	152	156	139	121	101	24	3

root but the uncontrolled values of shear are less near the tip. The differences in shear between the LQ, ES, and uncontrolled cases are not large.

The root locus of the eigenvalues of the wing with the LQ controller is shown in Fig. 5 as velocity is varied. The wing goes unstable at a velocity of about 295 m/s (the design condition was 275 m/s and the uncontrolled flutter speed was 241 m/s). It is interesting to note that for the LQ controller, one of the roots associated with the unsteady aerodynamic lag states goes unstable resulting in zero frequency flutter. In the uncontrolled case, the first bending model goes unstable in classical coupled mode flutter (Fig. 1). The root locus for the ES design is shown in Fig. 6. For the ES controller the wing goes unstable at a velocity of about 310 m/s. As in the uncontrolled case the first bending mode goes unstable, but in the controlled case the eigenvalues associated with this mode move to the real axis where one real root goes unstable resulting in zero frequency flutter.

The results of varying altitude while maintaining Mach number constant are shown in Fig. 7. At $M=0.86$, the uncontrolled wing is unstable until an altitude of 6700 m is reached. At the same Mach number, the LQ controller results in a stable wing at all altitudes above 3200 m and the ES controller stabilizes the wing above altitudes of 2900 m. At $M=0.7$ the uncontrolled wing is stable for altitudes above 1800 m whereas the ES controller stabilizes the




Fig. 5 Root Locus of LQ Controlled Wing as Velocity is Varied




Fig. 6 Root Locus of ES Controlled Wing as Velocity is Varied




Fig. 7 Flutter Boundaries for Uncontrolled, LQ, and ES Controlled Wing

wing for altitudes above 2100 m and the LQ controller stabilizes the wing for altitudes above 2400 m.

The ability of the ES and LQ systems to stabilize the wing in case of an actuator failure yielded little difference in the performance of the two systems. In the case where an inboard actuator failure was simulated, the outboard aileron was capable of stabilizing the wing with only small increases in rms surface activity (see Table 4). When the outboard actuator failed the inboard aileron was unable to stabilize the wing in both designs.

Since the outboard aileron is critical in stabilizing the wing, it is important to examine the stability margins associated with the outboard control loop. This can be accomplished by examining the loop transfer function

$$H(s)G(s) = K^T [Is - A]^{-1} B$$

Note since $u = +Kx$, the characteristic equation is given by

$$1 - G(s)H(s) = 0$$

and the critical condition occurs when the phase angle of $H(j\omega)G(j\omega)$ is zero. For the LQ design

$$H(s)G(s)_{LQ} = \frac{-148.8(s-2.6)}{(s^2 - 79.8s + (124.5)^2)}$$

It is interesting to note that the actuator poles, the poles associated with the unsteady aerodynamic lag states and all of the poles associated with the stable flexure modes have been cancelled by zeros. The only remaining poles are those associated with the unstable first bending mode. Bode diagrams for the LQ loop transfer function are




Fig. 8 Frequency Response of Magnitude of $\Pi(s)G(s)$ for LQ and ES Designs




Fig. 9 Frequency Response of Phase of $H(s)G(s)$ for LQ and ES Designs

given in Figs. 8 and 9. The gain margin is 6Db and the phase margins are 60°. This is not surprising, however, since Safanov and Athans [14] show that LQ controllers yield excellent gain and phase margins.

The loop transfer function for the ES controller is

$$H(s)G(s)_{ES} = \frac{51.45(s-427.4)(s-66.5)(s+42.4)}{(s^2-79.8s+(124.5)^2)(s^2+188.6s+(142.2)^2)}$$

Again all actuator poles and poles associated with unsteady aerodynamic lag states have been cancelled by zeros. But only the poles associated with the first torsion mode have been cancelled and the unstable first bending mode and stable second bending mode remain. Bode diagrams for this transfer function are also shown in Figs. 8 and 9. Gain margins are 6 Db or better but phase margins are less than 20°. Gain versus frequency plots for the LQ and ES transfer functions are very similar for frequencies above 10 rad/s. Both curves peak at the flutter frequency with a gain of 6 Db and then roll off with increasing frequency.

Conclusions

The ES and LQ controllers give very similar results in terms of required control surface activity. At the gust test condition the ES design exhibits lower wing root bending moment and shear than the LQ design but the LQ controller provides slightly lower torsional stress. Both the ES and LQ designs provide significantly reduced torsional stress at the wing root, slightly reduced shear, and

slightly increased bending moment compared with the open loop response. Both the LQ and ES controllers significantly increased flutter speed compared with the uncontrolled wing. The ES controller results in a slightly greater flutter speed than the LQ controller. For a fixed Mach number the ES design is stable at lower altitudes than the LQ design. The LQ design exhibits significantly better phase margins than the ES design at the flutter test condition. The gain margins are the same. Since the phase margins are determined near the flutter frequency, it is very important that the ES design be based on a model which is accurate in this frequency range. Both the LQ and ES designs exhibit excellent roll off at higher frequencies where modeling uncertainties are large.

The LQ design requires large feedback gains on the inboard actuator states. This reduces the overall inboard actuator gain. Increased forward loop gain would be required to restore open loop characteristics. This might necessitate redesign of existing actuator hardware. The ES controller does not require actuator feedback and the closed loop frequency response characteristics of the actuators is the same as the open loop case. Since the inboard actuator is not very effective for flutter control this is not an important consideration for the ARW-2, but could be critical in other applications. The ES controller requires only the structural and aerodynamic states, thus a lower-order observer could be used to realize this controller than would be required by the LQ controller. Finally the computational

algorithms required to calculate the ES controller gains are simpler and less expensive to use than those required to calculate the LQ controller gains.

The authors are currently working on ES design techniques that shape eigenvectors associated with uncontrollable states. It appears to be necessary to shape the eigenvectors associated with the gust states in order to further reduce rms control activity. Work is also in progress on improving ES stability margins and realization of ES controllers by means of observers and direct output feedback.

Doyle and Stein [15] have shown that if a Kalman Filter is used for state estimation, the robustness properties of full-state feedback can be recovered by introducing fictitious plant noise in the Ricatti equation used to obtain the filter gain matrix. As the magnitude of this plant noise approaches infinity, the filter poles asymptotically approach the transfer zeros (if the transfer zeros are in the right half of the complex plane the filter poles approach the mirror image of the zeros in the left half plane) or approach infinity in a Butterworth pattern. Since the Doyle-Stein procedure gives the location of the filter poles, it is possible to directly obtain the gain matrix which yields these poles using ES design techniques without solving the filter Ricatti equation. In the single-output, single-input case, this should yield the same result as obtained from solving the Ricatti equation; however, in the multi-input, multi-output case there is not a unique gain matrix

which yields a specified set of poles; thus, ES techniques will necessarily not yield the same results as obtained by the Doyle-Stein procedure. The utility of ES techniques in observer design should be studied in more detail. In addition, the effects on system performance of including flexure modes that were neglected during the design phase needs to be studied.

Acknowledgement

The results on ES design were obtained under Grant NAG-1-217 from NASA Langley Research Center. Mr. William Adams of NASA Langley and Mr. Sanjay Garg of the University of Minnesota were instrumental in developing and interpreting the mathematical models of the ARW-2. Mr. X.G. Li of the University of Minnesota played an important role in calculating the results for the LQ control system. Thanks are also due Dr. Thomas B. Cunningham of Honeywell, Inc. for a number of useful discussions concerning Eigenspace techniques.

References

1. Moore, B.C., "On the Flexibility Offered by Full-State Feedback in Multivariable Systems Beyond Closed Loop Eigenvalue Assignment," IEEE Trans. Auto. Control, Vol. 21, pp 682-691; 1976.
2. Cunningham, Thomas B., "Eigenspace Selection Procedures for Closed Loop Response Shaping with Modal Control," Proceedings IEEE Conference on Decision and Control; Dec. 1980.
3. Ostroff, A.J. and Pines, S., "Application of Modal Control to Wing - Flutter Suppression," NASA Tech Paper 1983; May 1982.
4. Newsom, J.R., "Control Law Synthesis for Active Flutter Suppression Using Optimal Control Theory," Journal of Guidance and Control, Vol. 2; Sept. - Oct. 1979 pp 388-394.
5. Abel, I., Newsom, J.R., and Dunn, H.J., "Application of Two Synthesis Methods for Active Flutter Suppression Using Linear Quadratic Gaussian Control Theory," AIAA Paper 79 - 1633; Aug. 1979.
6. Mahesh, J.K., Stone, C.R., Garrard, W.L., and Dunn, H.J., "Control Law Synthesis for Flutter Suppression Using Linear Quadratic Gaussian Control Theory," Journal of Guidance and Control, July - Aug., 1981, pp 415-422.
7. Mukhopadhyay, V., Newsom, J.R., and Abel, I., "Reduced-Order Optimal Feedback Control Law Synthesis for Flutter Suppression," Journal of Guidance and Control, July - Aug. 1981, pp 382-395.

8. Gangsaas, D., Ly, U., and Norman, D.C., "*Practical Gust Load Alleviation and Flutter Suppression Control Law Based on LQG Methodology*," AIAA Paper 81 - 0021, Jan. 1981.
9. Gangsaas, D., and Ly, U., "*Application of a Modified Linear Quadratic Gaussian Design to Active Control of a Transport Airplane*," AIAA Paper 79 - 1746, Aug. 1979.
10. Dowell, Earl H., "*A Simple Method for Converting Frequency Domain Aerodynamics to the Time Domain*," NASA Tech Memo 81844, Oct. 1980.
11. Noble, Ben, and Daniel, James W., "*Applied Linear Algebra*," 2nd Edition, Sections 9.6 and 11.6, Prentice Hall, 1977.
12. Adams, William M., Jr. and Tiffany, Sherwood H., "*An Updated Comparison of NASA/Boeing Predictions of the Open Loop, Symmetric Flutter Characteristics of the DAST ARW-2*," APCO TM 81-1, NASA Langley Research Center, Hampton VA, Jan. 1981.
13. Kwakernaak, H., and Sivan, Linear Optimal Control Systems, John Wiley and Sons, New York, 1972.
14. Safanov, M.G., and Athans, M., "*Gain and Phase Margins of Multi-Loop LQG Regulators*," IEEE Trans. Auto. Control, Vol. 22, pp 173-179, April 1977.
15. Doyle, J.C., and Stein, G., "*Multivariable Feedback Design: Concepts for a Classical Modern Synthesis*," IEEE Trans. Auto. Control, Feb. 1981.

Publications Issued During the Course of this Research

Active Flutter Suppression Using Eigenspace*
and Linear Quadratic Design Techniques

William L. Garrard and Bradley S. Liebst


University of Minnesota
Minneapolis, Minnesota

Abstract


Eigenspace (ES) and Linear Quadratic (LQ) techniques are used to design an active flutter suppression system for the DAST ARW-2 flight test vehicle. The performance of the ES and LQ controllers are very similar in meeting control surface activity specifications. The ES controller provides reduced wing root bending moment and shear but torsional stress is slightly higher than with the LQ controller. The ES controller also results in improved flutter boundaries compared with the LQ controller. The LQ controller exhibits significantly better phase margins at the flutter condition than does the ES controller but the LQ design requires large feedback gains on actuator states while the ES does not. This results in reduced overall actuator gain for the LQ design.

*This paper has been submitted to the AIAA Journal of Guidance, Control, and Dynamics.


Appendix A
Flexure Mode Shapes




(a) mode 1, frequency = 8.44 Hz, generalized mass = 0.0169 lb-sec²/in




(b) mode 2, frequency = 15.7 hz, generalized mass = 0.326 lb-sec²/in




(c) mode 3, frequency = 23.7 hz, generalized mass = 0.0153 lb-sec²/in




(d) mode 4, frequency = 31.7 Hz, generalized mass = 0.0158 lb-sec²/in




(e) mode 5, frequency = 39.3 Hz, generalized mass = 0.178 lb-sec²/in




(f) mode 6, frequency = 44.8 Hz, generalized mass = 0.593 lb-sec²/in




(g) mode 7, frequency = 47.3 Hz, generalized mass = 0.00335 lb-sec²/in



(h) mode 8, frequency = 66.6 Hz, generalized mass = $0.0621 \text{ lb-sec}^2/\text{in}$



(i) mode 9, frequency = 71.2 hz, generalized mass = 0.0286 lb-sec²/in



(j) mode 10, frequency = 80.5 Hz, generalized mass = 0.696 lb-sec²/in

Appendix B
Program Descriptions and Listings

FLUTTER

This program generates the coefficient matrices of the first order state equation

$$\dot{\bar{x}} = A\bar{x} + B\bar{u} + \Gamma\eta$$

This first order form is derived from the second order form

$$\begin{aligned} [M_{xx} + \bar{q} A_2^x (\frac{\bar{c}}{2V})^2] \ddot{\bar{x}} + [C_s + \bar{q} A_1^x (\frac{\bar{c}}{2V})] \dot{\bar{x}} + [K_s + \bar{q} A_0^x] \bar{x} \\ + \sum_{i=1}^L y_i + [M_{xu} + \bar{q} A_2^u (\frac{\bar{c}}{2V})^2] \ddot{\bar{u}} + \bar{q} A_1^u (\frac{\bar{c}}{2V}) \dot{\bar{u}} \\ + \bar{q} A_2^\delta (\frac{\bar{c}}{2V})^2 \ddot{\bar{\delta}} + \bar{q} A_1^\delta (\frac{\bar{c}}{2V}) \dot{\bar{\delta}} + \bar{q} A_0^\delta \bar{\delta} = 0 \end{aligned}$$

and $i=1,2,\dots,L$ aerodynamic lag states

$$\dot{y}_i = -I(\frac{2V}{\bar{c}}) K_i y_i + D_i^x \dot{\bar{x}} + D_i^u \dot{\bar{u}} + D_i^\delta \dot{\bar{\delta}}$$

or

$$\begin{aligned} \ddot{M\bar{x}} + \dot{C\bar{x}} + K\bar{x} + \sum_{i=1}^L y_i + \ddot{P\bar{u}} + \dot{Q\bar{u}} + \hat{R\bar{u}} + S\ddot{\bar{\delta}} \\ + T\dot{\bar{\delta}} + U\bar{\delta} = 0 \end{aligned}$$

and

$$\dot{y}_i = -I(\frac{2V}{\bar{c}}) K_i y_i + D_i^x \dot{\bar{x}} + E_i^u \dot{\bar{u}} + F_i^\delta \dot{\bar{\delta}}$$

where

$$M = M_{xx} + \bar{q} A_2^x (\frac{\bar{c}}{2V})^2$$

$$C = C_s + \bar{q} A_1^x (\frac{\bar{c}}{2V})$$

$$K = K_s + \bar{q} A_0^x$$

$$P = M_{xu} + \bar{q} A_2^u \left(\frac{\bar{c}}{2V}\right)^2$$

$$Q = \bar{q} A_1^u \left(\frac{\bar{c}}{2V}\right)$$

$$R = \bar{q} A_0^u$$

$$S = \bar{q} A_2^\delta \left(\frac{\bar{c}}{2V}\right)^2 \left(\frac{1}{V}\right)$$

$$T = \bar{q} A_1^\delta \left(\frac{\bar{c}}{2V}\right) \left(\frac{1}{V}\right)$$

$$U = \bar{q} A_0^\delta \left(\frac{1}{V}\right)$$

$$D_i = D_i^x$$

$$E_i = D_i^u$$

$$F_i = D_i^\delta \left(\frac{1}{V}\right)$$

\bar{x} = modal coordinates and rigid body modes

\hat{u} = control surface deflections

δ = vertical gust velocity

V = forward velocity

$$\bar{q} = \frac{1}{2} \rho V^2$$

\bar{c} = mean aerodynamic chord

Where the actuator-aileron dynamics are

$$\hat{\bar{u}} = J \bar{u}$$

$$\dot{\bar{u}} = G \bar{u} + H u$$

where

$$u = \begin{Bmatrix} u_o \\ u_i \end{Bmatrix} = \text{commanded control inputs}$$

$$\hat{\bar{u}} = \begin{Bmatrix} \bar{u}_o \\ \bar{u}_i \end{Bmatrix} = \text{control surface deflections}$$

$$u = \begin{Bmatrix} u_0 \\ u_1 \\ u_2 \\ u_3 \\ u_4 \\ u_5 \\ u_6 \\ u_7 \\ u_8 \\ u_9 \\ u_{10} \\ u_{11} \\ u_{12} \\ u_{13} \\ u_{14} \\ u_{15} \\ u_{16} \\ u_{17} \\ u_{18} \\ u_{19} \\ u_{20} \\ u_{21} \\ u_{22} \\ u_{23} \\ u_{24} \\ u_{25} \\ u_{26} \\ u_{27} \\ u_{28} \\ u_{29} \\ u_{30} \\ u_{31} \\ u_{32} \\ u_{33} \\ u_{34} \\ u_{35} \\ u_{36} \\ u_{37} \\ u_{38} \\ u_{39} \\ u_{40} \\ u_{41} \\ u_{42} \\ u_{43} \\ u_{44} \\ u_{45} \\ u_{46} \\ u_{47} \\ u_{48} \\ u_{49} \\ u_{50} \\ u_{51} \\ u_{52} \\ u_{53} \\ u_{54} \\ u_{55} \\ u_{56} \\ u_{57} \\ u_{58} \\ u_{59} \\ u_{60} \\ u_{61} \\ u_{62} \\ u_{63} \\ u_{64} \\ u_{65} \\ u_{66} \\ u_{67} \\ u_{68} \\ u_{69} \\ u_{70} \\ u_{71} \\ u_{72} \\ u_{73} \\ u_{74} \\ u_{75} \\ u_{76} \\ u_{77} \\ u_{78} \\ u_{79} \\ u_{80} \\ u_{81} \\ u_{82} \\ u_{83} \\ u_{84} \\ u_{85} \\ u_{86} \\ u_{87} \\ u_{88} \\ u_{89} \\ u_{90} \\ u_{91} \\ u_{92} \\ u_{93} \\ u_{94} \\ u_{95} \\ u_{96} \\ u_{97} \\ u_{98} \\ u_{99} \end{Bmatrix} = \text{control state}$$

$$G = \begin{bmatrix} 0 & 1.0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 1.0 & 0 & 0 & 0 & 0 \\ -1.774 \times 10^7 & -1.438 \times 10^5 & -431.0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 1.0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 1.0 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0 & 1.0 \\ 0 & 0 & 0 & -1.614 \times 10^{11} & -5.484 \times 10^8 & -1.152 \times 10^6 & -933.0 \end{bmatrix}$$

$$J = \begin{bmatrix} .514 & 0 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & .518 & 0 & 0 & 0 \end{bmatrix}$$

$$H = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ 1.774 \times 10^7 & 0 \\ 0 & 0 \\ 0 & 0 \\ 0 & 0 \\ 0 & 1.614 \times 10^{11} \end{bmatrix}$$

And the gust model is

$$\dot{z} = -\left(\frac{V}{\ell}\right)^2 \delta - 2\left(\frac{V}{\ell}\right) z - 2.464\left(\frac{V}{\ell}\right)^2 \eta$$

$$\dot{\delta} = z + 1.732\left(\frac{V}{\ell}\right) \eta$$

where z = an intermediate gust state

ℓ = characteristic gust length

η = white driving noise

Thus, if

$$x = \begin{pmatrix} \ddot{x} \\ \dot{x} \\ y_1 \\ y_2 \\ \vdots \\ y_L \\ \ddot{u} \\ \delta \\ z \end{pmatrix}$$

then neglecting $\ddot{s}\delta$ and $\ddot{p}\ddot{u}$

$$\Gamma = \begin{pmatrix} 0 \\ -M^{-1}T (1.732) \left(\frac{V}{\ell}\right) \\ F1 (1.732) \left(\frac{V}{\ell}\right) \\ F2 (1.732) \left(\frac{V}{\ell}\right) \\ \vdots \\ FL (1.732) \left(\frac{V}{\ell}\right) \\ 0 \\ (1.732) \left(\frac{V}{\ell}\right) \\ (-2.464) \left(\frac{V}{\ell}\right)^2 \end{pmatrix}$$

$$A = \begin{bmatrix} 0 & I & 0 & 0 & \dots & 0 & 0 & 0 & 0 \\ -M^{-1}K & -M^{-1}C & -M^{-1} & -M^{-1} & \dots & -M^{-1} & -M^{-1}(RJ+QJG) & -M^{-1}U & -M^{-1}T \\ 0 & D1 & -I\frac{2V}{c}K_1 & 0 & \dots & 0 & E1(JG) & 0 & F1 \\ 0 & D2 & 0 & -I\frac{2V}{c}K_2 & \dots & 0 & E2(JG) & 0 & F2 \\ \vdots & \vdots & \vdots & \vdots & \ddots & \vdots & \vdots & \vdots & \vdots \\ 0 & DL & 0 & 0 & \dots & -I\frac{2V}{c}K_L & EL(JG) & 0 & FL \\ 0 & 0 & 0 & 0 & \dots & 0 & G & 0 & 0 \\ 0 & 0 & 0 & 0 & \dots & 0 & 0 & 0 & 1.0 \\ 0 & 0 & 0 & 0 & \dots & 0 & 0 & -(\frac{V}{\ell})^2 & -2(\frac{V}{\ell}) \end{bmatrix}$$

$$B = \begin{Bmatrix} 0 \\ -M^{-1}QJH \\ E1(JH) \\ E2(JH) \\ \vdots \\ \vdots \\ EL(JH) \\ H \\ 0 \\ 0 \end{Bmatrix}$$

The open loop eigenvalues are also output. Open loop eigenvectors can be output as well.

MODAL

This program finds the optimal psuedo-inverse solution to the feedback gains (K) that achieve desired closed loop eigenvalue-eigenvector pairs (see Section on ES theory). The closed loop eigenvalues are also output. Closed loop eigenvectors can be output as well.

COV

This program finds the state covariance matrix for a given driving noise intensity. The rms aileron deflections and rates are determined as well.

LOADS

This program calculates the rms shear, bending moment, and torque at various station along the wing span.

FEEDBKE

This program calculates the closed loop eigenvalues at off design flight conditions.

82/12/15

PROGRAM FLUTTER

```

00100  PROGRAM FLUTTER( INPUT, OUTPUT, TAPE5=INPUT, TAPE6=OUTPUT, ONELE7,
00110+TAPE2=ONELE7, MASS, TAPE1=MASS, TAPE3)
00120C*****
00130C THIS PROGRAM INPUTS THE STRUCTURAL MASS, STRUCTURAL
00140C DAMPING, STRUCTURAL STIFFNESS, AERODYNAMIC INFLUENCE
00150C MATRICES, FLIGHT CONDITIONS AND OUTPUTS THE A, B, AND W
00160C MATRICES OF THE LINEAR STATE EQUATION
00170C      DX/DT = AX + BU + W
00180C      -FOR THE INBOARD AND OUTBOARD ATTACHMENTS AS CONTROLS.
00190C      OPEN LOOP EIGENVALUES AND EIGENVECTORS CAN BE OUTPUT
00200C      AS WELL.
00210C*****
00220  REAL MXX(8,8), CS(8,8), KS(8,8), CT(8,8), KT(8,8), CC(8,8),
00230+K(8,8), A2X(8,8), A1X(8,8), AOX(8,8), MINV(8,8), A2X0(8,8)
00240+, A1X0(8,8), AOX0(8,8), A1(16,16), A2(32,32), OQ(8,2), DUM1(8,7),
00250+DUM2(8,7), DUM3(8,2), DUM4(8,7), DUM5(8,2), DUM6(8,2), DUM7(8,1)
00260  REAL DUM8(8,1), AOU(8,2), A1U(8,2), EI(8,2,4), R(8,2),
00270+EI(8,7,4), FI(8,4), A3(40,40), B3(40,2), R2(32,2), I1(8,8),
00280+U(8,8,4), K1(4), A1D(8,1), AOD(8,1), T(8,1), U(8,1), A4(42,4),
00290+R4(42,2), W(42,1), B1(16,2), A5(24,24), B5(24,2)
00300  WRITE(6,8)
00310  8 FORMAT(1X, 'INPUT THE ORDER OF THE STRUCTURAL-RIGID BODY STATE VECTO
00320+R(N)')
00330  READ(5,*)N
00340  WRITE(6,10)
00350  10 FORMAT(1X, 'INPUT VELOCITY(U), CHORD(C), DYNAMIC PRESSURE(Q), NUMBE
00360+R OF LAG STATES(L)')
00370C
00380C INPUT FLIGHT CONDITIONS
00390C
00400  READ(5,10), C, Q, L
00410  DO 20 I=1, L
00420  WRITE(6,25)I
00430C
00440C INPUT AERODYNAMIC LAG FREQUENCIES
00450C
00460  READ(5,4)KT(1)
00470  20 CONTINUE
00480  25 FORMAT(1X, 'INPUT K1(, T1, )')
00490  N2=2*N
00500  KEND=N*(L+2)
00510  KENDN=KEND+7
00520  KEND2=KEND+2
00530  K5=21N+7

```

```

00560+,DUM5,DUM6,DUM7,DUM8,A0U,A1U,FI,R,ETIG,II,A3,B3,B2,FI,DI,K1,A10,
00570+A0D,T,U,A4,R1,B4,U,A5,B5)
-00580 STOP
00590 END
00600C
00610C
00620 SURROUTINE PROG1(N,N2,KEND,KENDD,KEND2,K5,V,C,R,L,MXX,CS,K5,CT,KT,
00630+CC,KK,A2X,A1X,A0X,MINV,A2XD,A1XD,A0XD,A1,A2,QD,DUM1,DUM2,DUM3,DUM4
00640+,DUM5,DUM6,DUM7,DUM8,A0U,A1U,ET,R,ETIG,II,A3,B3,B2,FI,DI,K1,A10,
00650+A0D,T,U,A4,R1,B4,U,A5,B5)
00660 REAL LAMDA,LL
00670 INTEGER FLAG
00680 COMMON KRET(42)
00690 REAL MXX(N,N),CS(N,N),KS(N,N),CT(N,N),KT(N,N),CC(N,N),KK(N,N),
00700+A2X(N,N),A1X(N,N),A0X(N,N),MINV(N,N),A2XD(N,N),A1XD(N,N),A0XD(N,N),
00710+,A1(N2,N2),A2(KEND,KENDD),QD(N,2),DUM1(N,7),DUM2(N,7),DUM3(N,2),
00720+DUM4(N,7),DUM5(N,2),DUM6(N,2),DUM7(N,1),DUM8(N,1),A0U(N,2)
00730 REAL A1U(N,2),
00740+EI(N,2,L),G(7,7),H(7,2),R(N,2),JG(2,7),EIIG(N,7,L),FI(N,L),
00750+JH(2,2),A3(KENDD,KENDD),R3(KENDD,2),B2(KEND,2),II(N,N),DI(N,N,L)
00760 REAL KI(L),A1D(N,1),A0D(N,1),T(N,1),U(N,1),A4(KEND2,KEND2),
00770+B1(N2,2),B4(KEND2,2),W(KEND2,1),
00780+A5(K5,K5),R5(K5,2),JJ(2,7)
00790 REAL AA(42,42),BB(42,2)
00800 CALL GETPF('SHTAPE1,4HMASS,0,0)
00810C
00820C READ IN STRUCTURAL DATA
00830C
00840 2 FORMAT(E16.8)
00850 DO 1 I=1,N
00860 * DO 1 J=1,N
00870 READ(1,101)MXX(I,J),CS(I,J),KS(I,J),KS(T,I)
00880 1 CONTINUE
00890 DO 3 I=1,7
00900 DO 3 J=1,7
00910C
00920C READ IN ACTUATOR DATA
00930C
00940 READ(1,101)G(I,J)
00950 3 CONTINUE
00960 DO 4 I=1,7
00970 READ(1,101)(H(I,J),J=1,2)
00980 4 CONTINUE
00990 DO 5 J=1,7
01000 READ(1,101)(JJ(I,J),I=1,2)
01010 5 CONTINUE
01020 CALL GETPF('SHTAPE2,6HONELE7,0,0)
01030C
01040C READ IN AERODYNAMIC INFLUENCE DATA

```

```

01060 DO 430 I=1,N
01070 DO 410 J=1,N
01080 DO 410 I=1,N
01090 READ(2,109)A0X(I,J),A1X(I,J),A2X(I,J),A1U(I,J),EI(I,J,K)
01100 410 CONTINUE
01110 DO 420 J=1,2
01120 DO 420 I=1,N
01130 READ(2,101)A0U(I,J),A1U(I,J),EI(I,J,K)
01140 420 CONTINUE
01150 DO 430 I=1,N
01160 READ(2,101)A0D(I,K),A1D(I,K),FI(I,K)
01170 FI(I,K)=FI(I,K)/V
01180 430 CONTINUE
01190 101 FORMAT(3E16.8)
01200 109 FORMAT(4E16.8)
01210 EPS=1.E-10
01220 TEMP=D+(C/2./V)**2
01230 TEMP2=D+C/2./V
01240 CALL SCAMAT(TEMP,A2X,A2XD,N,N)
01250 CALL MATADD(HXX,A2XD,MINV,N,N)
01260C
01270C
01280C
01290 CALL MXLNED(MINV,N,N,DET,IRANK,EPS,A2XD,0)
01300 CALL SCAMAT(TEMP2,A1X,A1XD,N,N)
01310 CALL MATADD(CS,A1XD,CT,N,N)
01320 CALL SCAMAT(0,A0X,A0XD,N,N)
01330 CALL MATADD(KS,A0XD,KT,N,N)
01340 CALL SCAMAT(-1.,MINV,MINV,N,N)
01350 CALL MATMUL(MINV,KT,KK,N,N,N)
01360 CALL MATMUL(MINV,CT,CC,N,N,N)
01370 DO 15 I=1,N
01380 DO 14 J=1,N
01390 FI(I,J)=0.
01400 14 CONTINUE
01410 FI(I,I)=1.0
01420 15 CONTINUE
01430 N21=N2+1
01440 DO 18 I=1,N
01450 DO 18 J=1,N
01460 A1(J,I)=0.
01470 A1(I,J+N)=FI(I,J)
01480 A1(I+N,J)=KK(I,J)
01490 A1(I+N,J+N)=CC(I,J)
01500 18 CONTINUE
01510 IF(L.EQ.0)GO TO 100
01520 DO 20 I=1,KEND
01530 DO 20 J=1,KEND
01540 A2(I,J)=0.
01550 20 CONTINUE

```

```

01580 A2(I,J)=A1(I,I)
01590 A2(I+N,J)=A1(I+N,J)
01600 A2(I,J+N)=A1(I,J+N)
01610 A2(I+N,J+N)=A1(I+N,I+N)
01620 DO 25 K=1,L
01630 KN=K+N
01640 A2(I+N,KN+N+J)=MINV(I,J)
01650 A2(KN+N+I,J+N)=DI(I,J,K)
01660 A2(KN+N+I,KN+N+I)=-2.*V*KI(K)/C
01670 25 CONTINUE
01680 WRITE(6,27)
01690 27 FORMAT(1X,'SHOULD THE CONTROL MATRIX B ALSO BE CALCULATED? YES(1),
01700+ NO(0)')
01710 READ(5,28)MM
01720 28 FORMAT(I1)
01730 IF(MM.EQ.1)GO TO 30
01740 FLAG=2
01750 GO TO 200
01760 30 SCA=Q+C/2./V
01770 CALL SCAMAT(SCA,A1U,QQ,N,2)
01780 CALL SCAMAT(Q,AOU,R,N,2)
01790 DO 36 I=1,KEND
01800 DO 36 J=1,KEND
01810 A3(I,J)=0.
01820 36 CONTINUE
01830 DO 37 I=1,KEND
01840 DO 37 J=1,KEND
01850 A3(I,J)=A2(I,J)
01860 37 CONTINUE
01870 DO 38 I=1,7
01880 DO 38 J=1,7
01890 A3(KEND+I,KEND+J)=G(I,J)
01900 38 CONTINUE
01910 CALL MATMUL(JJ,G,JG,2,7,7)
01920 CALL MATMUL(QQ,JG,DUM1,N,2,7)
01930 CALL MATMUL(R,JJ,DUM2,N,2,7)
01940 CALL MATADD(DUM2,DUM1,DUM1,DUM2,N,7)
01950 CALL MATMUL(MINV,DUM2,DUM1,N,N,7)
01960 DO 40 K=1,L
01970 DO 39 I=1,N
01980 DO 39 J=1,2
01990 DUM3(I,J)=EI(I,J,K)
02000 39 CONTINUE
02010 CALL MATMUL(DUM3,JG,DUM4,N,2,7)
02020 DO 40 I=1,N
02030 DO 40 J=1,7
02040 EI JG(I,J,K)=DUM4(I,J)
02050 40 CONTINUE
02060 DO 45 I=1,N

```

```

02090      CALL IJG(I,J,KEND)=EI IJG(I,J,K)
02100      KN=K+N
02110      A3(KN+N+I,J+KEND)=EI IJG(I,J,K)
02120      45 CONTINUE
02130      CALL MATMUL(JJ,H,JH,2,2,2)
02140      CALL MATMUL(DD,JH,DUM3,N,2,2)
02150      CALL MATMUL(MINV,DUM3,DUM5,N,N,2)
02160      DO 47 K=1,L
02170      DO 46 I=1,N
02180      DO 46 J=1,2
02190      DUM3(I,J)=EI(I,J,K)
02200      46 CONTINUE
02210      CALL MATMUL(DUM3,JH,DUM6,N,2,2)
02220      DO 47 I=1,N
02230      DO 47 J=1,2
02240      EIJG(I,J,K)=DUM6(I,J)
02250      47 CONTINUE
02260      DO 48 I=1,N
02270      DO 48 J=1,2
02280      B3(I,J)=0.
02290      B3(I+N,J)=DUM5(I,J)
02300      DO 48 K=1,L
02310      KN=K+N
02320      B3(I+KN+N,J)=EIJG(I,J,K)
02330      48 CONTINUE
02340      DO 49 I=1,7
02350      DO 49 J=1,2
02360      B3(I+KEND,J)=H(I,J)
02370      49 CONTINUE
02380      WRITE(6,50)
02390      50 FORMAT(1X,'SHOULD THE NOISE VECTOR (U) ALSO BE CALCULATED? YES(1),
02400+NO(0)')
02410      READ(5,28)MM
02420      IF(MM.EQ.1)GO TO 55
02430      FLAG=3
02440      GO TO 200
02450      55 WRITE(6,56)
02460      56 FORMAT(1X,'INPUT CHARACTERISTIC LENGTH(LL)')
02470      READ(5,4)LL
02480      TEMP3=TEMP2/V
02490      CALL SCAMAT(TEMP3,AID,I,N,1)
02500      O1=O/V
02510      CALL SCAMAT(O1,AOD,U,N,1)
02520      CALL MATMUL(MINV,U,DUM7,N,N,1)
02530      CALL MATMUL(MINV,I,DUM8,N,N,1)
02540      DO 58 I=1,KEND
02550      DO 58 J=1,2
02560      B4(I,J)=B3(I,J)
02570      B4(KFNND+1,J)=0.

```

```

02600 DO 59 I=1,KEND2
02610 DO 59 J=1,KEND2
02620 A4(I,J)=0.
02630 59 CONTINUE
02640 DO 60 I=1,KEND0
02650 DO 60 J=1,KEND0
02660 A4(I,J)=A3(I,J)
02670 60 CONTINUE
02680 A4(KEND0+1,KEND0+2)=1.
02690 A4(KEND0+2,KEND0+1)=-1.001*(V/LL)*+?
02700 A4(KEND0+2,KEND0+2)=-2.001*V/LL
02710 DO 62 I=1,N
02720 A4(I+N,KEND0+1)=DUM7(I,1)
02730 A4(I+N,KEND0+2)=DUM8(I,1)
02740 DO 62 K=1,L
02750 KN=K*N
02760 A4(I+KN+N,KEND0+2)=FI(I,K)
02770 62 CONTINUE
02780 DO 64 I=1,KEND2
02790 W(I,1)=0.
02800 64 CONTINUE
02810 XX=1.732*V/LL
02820 W(KEND0+1,1)=XX
02830 W(KEND0+2,1)=-2.444*(V/LL)*+2
02840 CALL SCAMAT(XX,DUM8,DUM8,N,1)
02850 DO 66 J=1,N
02860 W(I+N,1)=DUM8(I,1)
02870 DO 66 K=1,L
02880 KN=K*N
02890 W(I+KN+N,1)=XX*FI(I,K)
02900 66 CONTINUE
02910 FLAG=4
02920 GO TO 200
02930 100 WRITE(6,27)
02940 READ(5,28)NM
02950 IF(NM.EQ.1)GO TO 102
02960 FLAG=1
02970 GO TO 200
02980 102 SCA=D*C/2./V
02990 CALL SCAMAT(SCA,A10,00,N,2)
03000 CALL SCAMAT(Q,A00,R,N,2)
03010 DO 106 I=1,K5
03020 DO 106 J=1,K5
03030 A5(I,J)=0.
03040 106 CONTINUE
03050 CALL MATMUL(J,J,H,JH,2,7,2)
03060 CALL MATMUL(OO,JH,DUM3,N,2,2)
03070 CALL MATMUL(HTNU,DUM3,DUM5,N,N,2)
03080 DO 108 I=1,N

```



```

03110 R5(I+N,J)=DUM5(I,J)
03120 108 CONTINUE
03130 DO 110 I=1,7
03140 DO 110 J=1,2
03150 R5(I+N2,J)=H(I,J)
03160 110 CONTINUE
03170 DO 112 I=1,N2
03180 DO 112 J=1,N2
03190 A5(I,J)=A1(I,J)
03200 112 CONTINUE
03210 CALL MATMUL(JJ,6,JG,2,,7)
03220 CALL MATMUL(QQ,JG,DUM1,N,2,7)
03230 CALL MATMUL(R,JJ,DUM2,N,2,7)
03240 CALL MATADD(DUM2,DUM1,DUM2,N,7)
03250 CALL MATMUL(MINV,DUM2,DUM1,N,N,7)
03260 DO 114 I=1,N
03270 DO 114 J=1,7
03280 A5(I+N,J+N2)=DUM1(J,J)
03290 114 CONTINUE
03300 DO 116 I=1,7
03310 DO 116 J=1,7
03320 A5(I+N2,J+N2)=6(I,J)
03330 116 CONTINUE
03340 FLAG=5
03350 200 WRITE(6,201)
03360 201 FORMAT(1X,'INPUT RETAIN(I) OR DELETE(0) FOR EACH STATE MEMBER'//)
03370 KSTATE=N
03380 KSUM=0
03390 READ(5,*)(KRET(J),J=1,KSTATE)
03400 DO 205 I=1,KSTATE
03410 KRET(I+N)=KRET(I)
03420 IF(KRET(I).EQ.1)KSUM=KSUM+1
03430 205 CONTINUE
03440 IF(L.EQ.0)GO TO 207
03450 DO 206 K=1,L
03460 DO 206 T=1,N
03470 KN=N*(K+1)+I
03480 KRET(KN)=KRET(I)
03490 206 CONTINUE
03500 DO 209 I=1,9
03510 KRET(KEND+I)=I
03520 209 CONTINUE
03530 207 GO TO(310,320,330,340,350),FLAG
03540 310 KSUM=2*KSUM
03550 CALL PROG2(FLAG,KSUM,A1,B1,N2,AA,BB)
03560 GO TO 900
03570 320 KSUM=(1+2)*KSUM
03580 CALL PROG2(FLAG,KSUM,A2,B2,KEND,AA,BB)
03590 GO TO 900

```

```

03620      GO TO 900
03630      KSUM=9+(1+2)*KSUM
03640      DO 341 J=1,KEND2
03650      IF(KRET(I).EQ.0)GO TO 341
03660      WRITE(3,2)U(I,1)
03670      341 CONTINUE
03680      CALL PR062(FLAG,KSUM,A4,B4,KEND2,AA,BB)
03690      GO TO 900
03700      KSUM=7+2*KSUM
03710      DO 351 I=N21,K5
03720      KRET(I)=1
03730      351 CONTINUE
03740      CALL PR062(FLAG,KSUM,A5,B5,K5,AA,BB)
03750      900 RETURN
03760      END
03770C
03780C
03790      SUBROUTINE MATDEL(A,N,AA,KSUM)
03800C
03810C      THIS ROUTINE DELETES DESIRED STATES FROM THE A MATRIX
03820C
03830      DIMENSION A(N,N),AA(KSUM,KSUM),JRET(40)
03840      COMMON KRET(42)
03850      J=0
03860      DO 100 I=1,N
03870      IF(KRET(I).EQ.0)GO TO 100
03880      J=J+1
03890      JRET(J)=I
03900      100 CONTINUE
03910      DO 200 I=1,KSUM
03920      DO 200 J=1,KSUM
03930      AA(I,J)=A(JRET(I),JRET(J))
03940      200 CONTINUE
03950      RETURN
03960      END
03970C
03980C
03990      SUBROUTINE MATDEL(B,N,BB,KSUM)
04000C
04010C      THIS ROUTINE DELETES DESIRED STATES FROM THE B MATRIX
04020C
04030      DIMENSION B(N,2),BB(KSUM,2),JRET(40)
04040      COMMON KRET(42)
04050      J=0
04060      DO 100 I=1,N
04070      IF(KRET(I).EQ.0)GO TO 100
04080      J=J+1
04090      JRET(J)=I
04100      100 CONTINUE

```

“PAGE MISSING FROM AVAILABLE VERSION”

PAGE 73

```

04130 RR(I,J)=R(RRET(I,J))
04140 200 CONTINUE
04150 RETURN
04160 END
04170C
04180C
04190C.....T(M,P)=A(M,N) * U(M,P)
04200 SUBROUTINE MATMUL(A,U,T,M,N,P)
04210 INTEGER P
04220 DIMENSION A(M,N),U(N,P),T(M,P)
04230 DO 1 I=1,M
04240 DO 1 J=1,P
04250 T(I,J)=0.
04260 1 CONTINUE
04270 DO 2 I=1,M
04280 DO 2 J=1,P
04290 DO 2 K=1,N
04300 T(I,J)=A(I,K)*U(K,J)+T(I,J)
04310 2 CONTINUE
04320 RETURN
04330 END
04340C
04350C
04360C.....C(M,N)=A(M,N) + B(M,N)
04370 SUBROUTINE MATADD(A,B,C,M,N)
04380 DIMENSION A(M,N),B(M,N),C(M,N)
04390 DO 3 I=1,M
04400 DO 3 J=1,N
04410 C(I,J)=A(I,J)+B(I,J)
04420 3 CONTINUE
04430 RETURN
04440 END
04450C
04460C
04470C.....B(M,N)=S * A(M,N)
04480 SUBROUTINE SCMAT(S,A,B,M,N)
04490 DIMENSION A(M,N),B(M,N)
04500 DO 8 I=1,M
04510 DO 8 J=1,N
04520 B(I,J)=S*A(I,J)
04530 8 CONTINUE
04540 RETURN
04550 END
04560C
04570C
04580C.....V(N,M)= A(M,N) TRANPOSED
04590 SUBROUTINE MATTRA(A,V,M,N)
04600 DIMENSION A(M,N),V(N,M)
04610 DO 14 I=1,M

```

```

04630      V(I,J)=R(I,J)
04640      14 CONTINUE
04650      RETURN
04660      ENH
04670C
04680C
04690      SUBROUTINE PRO62(FLAG,KSUM,AA,B,IP,AA,BB)
04700      INTEGER FLAG,IV1(42)
04710      REAL AA(KSUM,KSUM),BB(KSUM,2),A(IP,(P),B(IP,2),FV1(42)
04720      REAL UR(42),UI(42),Z(42,42)
04730      GO TO(310,320,330,340,350),FLAG
04740      100 FORMAT(3E16.8)
04750      310 CALL MATDEL(A,IP,AA,KSUM)
04760      DO 311 I=1,KSUM
04770      DO 311 J=1,KSUM
04780      WRITE(3,100)AA(I,J)
04790      311 CONTINUE
04800      6040P8063(KSUM,AA,UR,UI,Z,IV1,FV1)
04810      320 604B2MATDEL(KSUM,AA,KSUM)
04820      DO 321 J=1,KSUM
04830      WRITE(3,100)AA(I,J)
04840      321 CONTINUE
04850      CALL PRO63(KSUM,AA,UR,UI,Z,IV1,FV1)
04860      GO TO 900
04870      330 CALL MATDEL(A,IP,AA,KSUM)
04880      CALL MATDEL(B,IP,BB,KSUM)
04890      DO 331 I=1,KSUM
04900      DO 331 J=1,KSUM
04910      WRITE(3,100)AA(I,J)
04920      331 CONTINUE
04930      DO 332 I=1,KSUM
04940      WRITE(3,100)BB(I,1),BB(I,2)
04950      332 CONTINUE
04960      CALL PRO63(KSUM,AA,UR,UI,Z,IV1,FV1)
04970      GO TO 900
04980      340 CALL MATDEL(A,IP,AA,KSUM)
04990      CALL MATDEL(B,IP,BB,KSUM)
05000      DO 341 I=1,KSUM
05010      DO 341 J=1,KSUM
05020      WRITE(3,100)AA(I,J)
05030      341 CONTINUE
05040      DO 342 I=1,KSUM
05050      WRITE(3,100)BB(I,1),BB(I,2)
05060      342 CONTINUE
05070      CALL PRO63(KSUM,AA,UR,UI,Z,IV1,FV1)
05080      GO TO 900
05090      350 CALL MATDEL(A,IP,AA,KSUM)
05100      CALL MATDEL(B,IP,BB,KSUM)
05110      DO 351 I=1,KSUM
05120      DO 351 J=1,KSUM
05130      DO 351 J=1,KSUM
05140

```

```

05170 DO 352 I=1,KSUM
05180 WRITE(3,100)BB(I,1),BB(I,2)
05190 352 CONTINUE
05200 CALL PROG3(KSUM,AA,WR,WI,Z,IV1,FV1)
05210 900 CALL REPLAC(5HTAPE3,SHFLE9,0,0)
05220 RETURN
05230 END
05240C
05250C
05260
05270 SUBROUTINE PROG3(N,AA,WR,WI,Z,IV1,FV1)
05280 COMMON KRET(42)
05290C DIMENSION AA(N,N),WR(N),WI(N),Z(N,N),IV1(N),FV1(N)
05300C
05310C CALCULATE EIGENVALUES AND EIGENVECTORS OF AA
05320
05330 CALL RG(N,N,AA,WR,WI,1,Z,IV1,FV1,IERR)
05340 WRITE(6,23)
05350 23 FORMAT(41X,'OPEN LOOP EIGENVALUES'/31X,'REAL PART',20X,
05360 'IMAGINARY PART')
05370 DO 30 I=1,N
05380 WRITE(6,25)I,WR(I),WI(I)
05390 25 FORMAT(20X,I2,'.',2X,E15.4,15X,E15.4)
05400 30 CONTINUE
05410C
05420C WRITE(6,55)
05430 55 FORMAT(1X,'DO YOU WANT THE OPEN LOOP EIGENVECTORS OUTPUT? YES(1)
05440 'NO(0)')
05450 READ(5,*)MM
05460 IF(MM.EQ.0)GO TO 60
05470 WRITE(6,64)
05480 64 FORMAT(1X,'INPUT PRINT(1) OR SUPPRESS(0) FOR EACH EIGENVECTOR')
05490 READ(5,*)(KRET(J),J=1,N)
05500C WRITE(6,34)
05510 34 FORMAT(41X,'OPEN LOOP EIGENVECTORS'/31X,'REAL PART',20X,
05520 'IMAGINARY PART')
05530 IFLAG=0
05540 DO 50 J=1,N
05550 IF(KRET(J).EQ.0)GO TO 49
05560 IF(WI(J).NE.0.0)GO TO 35
05570 DO 37 I=1,N
05580 IF(I.NE.1)GO TO 36
05590 WRITE(6,38)J,Z(1,J)
05600 38 FORMAT(//20X,I2,'.',2X,E15.4,20X,'0.0')
05610 60 TO 37
05620 16 WRITE(6,39)Z(1,J)
05630 39 FORMAT(25X,E15.4,20X,'0.0')
05640 37 CONTINUE
05650 60 TO 50
05660 35 IF(IFLAG.EQ.1)GO TO 40
05670 IFLAG=1

```

```
05680 WRITE(6,43)J,Z(I,J),Z(I,J+1)
05690 43 FORMAT(//20X,I2,' ',2X,E15.4,15X,E15.4)
05700 60 TO 41
05710 42 WRITE(6,44)Z(I,J),Z(I,J+1)
05720 44 FORMAT(25X,E15.4,15X,E15.4)
05730 41 CONTINUE
05740 60 TO 50
05750 40 J1=J-1
05760 WRITE(6,45)J,J1
05770 45 FORMAT(//20X,I2,' ',5X,'CONJUGATE OF EIGENVECTOR',IX,I2,' ')
05780 49 IFLAG=0
05790 50 CONTINUE
05800 60 RETURN
05810 END
```

```

R2/17/15
NNFTS      PROGRAM      MODAL
00100      PROGRAM MODAL(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT,FTLE3,
00110+TAPE1=FILE3,TAPE3)
00120C*****
00130C      THIS PROGRAM INPUTS THE STATE MATRICES(OUTPUT
00140C      OF FLUTTER) A, B, W, DESIRFD CLOSED
00150C      LOOP EIGENVALUES AND EIGENVECTORS, THE EIGENVECTOR
00160C      WEIGHTING MATRIX AND OUTPUTS THE GAIN MATRIX K WHERE
00170C      U = KX
00180C      THE CLOSED LOOP EIGENVALUES AND EIGENVECTORS THAT WERE
00190C      ACHIEVED CAN RE OUTPUT AS UFILE.
00200C*****
00210      DIMENSION A(42,42),WR(2,42),W(2,42),Z(42,42),IV1(42),
00220+FU1(42),VECD(42,42),VECD(42,42),ERD(42),EID(42),KRET(2,42),W(42,1),
00230+R(42,2)
00240      WRITE(6,10)
00250      10 FORMAT(1X,'INPUT ORDER OF SYSTEM')
00260      READ(5,*)N
00270      CALL PROG1(N,A,WR,WI,Z,IV1,FU1,VECD,VECD,ERD,EID,KRET,
00280+W,R)
00290      STOP
00300      END
00310C
00320C
00330      SUBROUTINE PROG1(N,A,WR,WI,Z,IV1,FU1,VECD,VECD,ERD,EID,
00340+KRET,W,R)
00350      DIMENSION A(N,N),WR(2,N),W(2,N),Z(N,N),IV1(N),FU1(N),
00360+VECD(N,N),VECD(N,N),ERD(N),EID(N),KRET(2,N),W(N,1),B(N,2)
00370      REAL IJ(42,42),LB(84,4),LBT(4,84)
00380      DIMENSION OB(84,84),OB(84,1),YB(84,84),PP(42,2),DV(42,1),
00390+BR(84,4),C(42,42),P(84,1)
00400      N2=N*2
00410      NM1=N-1
00420      NM2=N-2
00430      WRITE(6,11)
00440      11 FORMAT(1X,'IS THE NOISE VECTOR (W) BEING INPUT? YES(1), NO(0)')
00450      READ(5,12)NM
00460      12 FORMAT(11)
00470C
00480C
00490C      READ IN STATE MATRICES OUTPUT FROM PROGRAM: FLUTTER
00500      CALL GETPF(5HTAPE1,5HFILE3,0,0)
00510      IF(MM.EQ.0)GO TO 14
00520      DO 13 I=1,N
00530          READ(1,15)W(I,1)

```



```

00560 DO 16 I=1,N
00570 DO 16 J=1,N
00580 READ(1,15)A(I,J)
00590 16 CONTINUE
00600 DO 17 I=1,N
00610 READ(1,15)B(I,1),B(I,2)
00620 17 CONTINUE
00630 DO 24 I=1,N
00640 DO 24 J=1,N
00650 VECRD(I,J)=A(I,J)
00660 24 CONTINUE
00670C
00680C
00690C
00700 CALL RG(N,N,VECRD,ERD,EID,1,Z,IV1,FU1,IERR)
00710 WRITE(6,23)
00720 23 FORMAT(41X,'OPEN LOOP EIGENVALUES'/31X,'REAL PART',20X,
00730+'IMAGINARY PART')
00740 DO 30 I=1,N
00750 WRITE(6,25)I,ERD(I),EID(I)
00760 25 FORMAT(20X,I2,' ',2X,E15.4,15X,E15.4)
00770 30 CONTINUE
00780 IFLAG=0
00790 DO 50 J=1,N
00800 IF(EID(J).NE.0.0)GO TO 35
00810 KRET(I,J)=0
00820 DO 37 I=1,N
00830 IF(I.NE.1)GO TO 36
00840 VECRD(I,J)=7(I,J)
00850 VECID(I,J)=0.0
00860 GO TO 37
00870 36 VECRD(I,J)=Z(I,J)
00880 VECID(I,J)=0.0
00890 37 CONTINUE
00900 GO TO 50
00910 35 KRET(I,J)=IFLAG
00920 7F(IFLAG.EQ.1)GO TO 40
00930 IFLAG=1
00940 DO 41 I=1,N
00950 IF(I.NE.1)GO TO 42
00960 VECRD(I,J)=Z(I,J)
00970 VECID(I,J)=Z(I,J+1)
00980 GO TO 41
00990 42 VECRD(I,J)=Z(I,J)
01000 VECID(I,J)=Z(I,J+1)
01010 41 CONTINUE
01020 GO TO 50
01030 40 J1=J-1
01040 DO 46 T=1,N

```

```

01069  VECT(I, I)=0.0, I
01070  44 CONTINUE
01080  TFLAG=0
01090  50 CONTINUE
01100  WRITE(6,100)
01110  100 FORMAT(1X,'INPUT RETAIN(1) OR CHANGE(0) FOR EACH EIGENSOLUTION')
01120  READ(5,*)(KRET(2,J),J=1,N)
01130  DO 110 J=1,N
01140  IF(KRET(2,J).EQ.1)GO TO 120
01150  IF(KRET(1,J).EQ.0)GO TO 105
01160  I1=I-1
01170  WRITE(6,107)I,I1
01180  107 FORMAT(1X,'DESIRED EIGENVALUE ',I2,'. WILL BE ENTERED AS THE CONJ
01190+UGATE OF DESIRED EIGENVALUE ',I2,'.')
01200  ERD(I)=ERD(I1)
01210  EID(I)=-EID(I1)
01220  GO TO 110
01230  105 IF(VECRD(NH1,I).NE.0..OR.VECRD(N,I).NE.0.)GO TO 110
01240  WRITE(6,101)I
01250  101 FORMAT(1X,'INPUT DESIRED REAL PART, IMAGINARY PART OF NEW',I,
01260+'EIGENVALUE ',I2,'.')
01270  READ(5,*)FRD(I),EID(I)
01280  GO TO 110
01290  120 DO 121 J=1,2
01300  WR(J,I)=0.
01310  WI(J,I)=0.
01320  121 CONTINUE
01330  110 CONTINUE
01340  DO 140 I=1,N
01350  IF(KRET(2,I).EQ.1)GO TO 140
01360  IF(KRET(1,I).EQ.0)GO TO 113
01370  I1=I-1
01380  WRITE(6,114)I,I1
01390  114 FORMAT(1X,'DESIRED EIGENVECTOR ',I2,'. WILL BE ENTERED AS THE CONJ
01400+UGATE OF DESIRED EIGENVECTOR ',I2,'.')
01410  DO 115 J=1,N
01420  VECRD(J,I)=VECRD(J,I1)
01430  VECID(J,I)=-VECID(J,I1)
01440  115 CONTINUE
01450  GO TO 140
01460  113 WRITE(6,111)I
01470  111 FORMAT(1X,'INPUT DESIRED REAL PART, IMAGINARY PART OF NEW EIGENVECT
01480+'OR ',I2,'.')
01490  JN=N
01500  IF(VECRD(NH1,I).NE.0..OR.VECRD(N,I).NE.0.)JN=NM2
01510  DO 112 J=1,JN
01520  READ(5,*)VECRD(J,I),VECID(J,I)
01530  112 CONTINUE
01540  140 CONTINUE
01550  DO 150 I=1,N

```

[illegible]

```

02090 T(I,J)=0.
02100 1 CONTINUE
02110 DO 2 I=1,M
02120 DO 2 J=1,P
02130 DO 2 K=1,N
02140 T(I,J)=A(I,K)+U(K,J)+T(I,J)
02150 2 CONTINUE
02160 RETURN
02170 END
02180C
02190C
02200C.....C(M,N)=A(M,N) + B(M,N)
02210 SUBROUTINE MATADD(A,B,C,M,N)
02220 DIMENSION A(M,N),B(M,N),C(M,N)
02230 DO 3 I=1,M
02240 DO 3 J=1,N
02250 C(I,J)=A(I,J)+B(I,J)
02260 3 CONTINUE
02270 RETURN
02280 END
02290C
02300C
02310C.....B(M,N)=S * A(M,N)
02320 SUBROUTINE SCAMAT(S,A,B,M,N)
02330 DIMENSION A(M,N),B(M,N)
02340 DO 8 I=1,M
02350 DO 8 J=1,N
02360 B(I,J)=S*A(I,J)
02370 8 CONTINUE
02380 RETURN
02390 END
02400C
02410C
02420C.....V(N,M)= A(M,N) TRANSPOSED
02430 SUBROUTINE MATTRA(A,V,M,N)
02440 DIMENSION A(M,N),V(N,M)
02450 DO 14 I=1,M
02460 DO 14 J=1,N
02470 V(J,I)=A(I,J)
02480 14 CONTINUE
02490 RETURN
02500 END
02510C
02520C
02530C
02540 SUBROUTINE PROG3(N,AA,UR,U,I,Z,IV,I,FOI,KRET)
02550 DIMENSION AA(N,N),UR(N),UI(N),7(N,N),IUI(N),FOI(N),KRET(2,N)
02560C
02570C CALCULATE CLOSED LOOP EIGENVALUES AND EIGENVECTORS

```

```

02600 WRITE(6,23)
02610 23 FORMAT(41X,'CLOSED LOOP EIGENVALUES'/31X,'TOTAL PART',20X,
02620+'IMAGINARY PART')
02630 DO 30 I=1,N
02640 WRITE(6,25)I,WR(I),WJ(I)
02650 25 FORMAT(20X,I2,' ',2X,E15.4,15X,E15.4)
02660 30 CONTINUE
02670 WRITE(6,55)
02680 55 FORMAT(1X,'DO YOU WANT THE CLOSED LOOP EIGENVECTORS OUTPUT? YES(1)
02690+',NO(0)')
02700 READ(5,*)MM
02710 IF(MM.EQ.0)GO TO 60
02720 WRITE(6,64)
02730 64 FORMAT(1X,'INPUT PRINT(1) OR SUPPRESS(0) FOR EACH EIGENVECTOR')
02740 READ(5,*)(KRET(I),J),J=1,N
02750 WRITE(6,34)
02760 34 FORMAT(41X,'CLOSED LOOP EIGENVECTORS'/31X,'REAL PART',20X,
02770+'IMAGINARY PART')
02780 IFLAG=0
02790 DO 50 J=1,N
02800 IF(KRET(I),J).EQ.0)GO TO 49
02810 IF(WI(J).NE.0.0)GO TO 35
02820 DO 37 I=1,N
02830 IF(I.NE.1)GO TO 36
02840 WRITE(6,38)J,Z(I,J)
02850 38 FORMAT('//20X,I2,' ',2X,E15.4,'20X,'0.0')
02860 GO TO 37
02870 36 WRITE(6,39)Z(I,J)
02880 39 FORMAT(25X,E15.4,20X,'0.0')
02890 37 CONTINUE
02900 GO TO 50
02910 35 IF(IFLAG.EQ.1)GO TO 40
02920 IFLAG=1
02930 DO 41 I=1,N
02940 IF(I.NE.1)GO TO 42
02950 WRITE(6,43)I,Z(I,J),Z(I,J+1)
02960 43 FORMAT('//20X,I2,' ',2X,E15.4,15X,E15.4)
02970 GO TO 41
02980 42 WRITE(6,44)Z(I,J),Z(I,J+1)
02990 44 FORMAT(25X,E15.4,15X,E15.4)
03000 41 CONTINUE
03010 GO TO 50
03020 40 J1=J-1
03030 WRITE(6,45)I,J1
03040 45 FORMAT('//20X,I2,' ',5X,'CONJUGATE OF EIGENVECTOR',1X,I2,' ')
03050 49 IFLAG=0
03060 50 CONTINUE
03070 60 RETURN
03080 END

```

```

03110      SUBROUTINE PR062(ID,ERD,ETD,UR,UI,VECRD,VECTD,A,B,N,N2,OR,LB,YR,
03120+RB,II,LBT,UB,P,C)
03130      DIMENSION ERD(N),ETD(N),UR(2,N),UI(2,N),VECRD(N,N),VECTD(N,N),
03140+AIN(N),R(N,2),OR(N2,N2),UB(4,1),VB(N2,1),YB(N2,N2),RB(N2,4),
03150+C(N,N),R(4,4),P(N2,1),T(4,1),RR(4,4)
03160      REAL II(N,N),LB(N2,4),LBT(4,N2),LAMR,LAMI
03170      LAMR=ERD(ID)
03180      LAMI=ETD(ID)
03190      DO 5 I=1,N
03200      VB(I,1)=VECRD(I,TD)
03210      VR(J+N,1)=VECTD(I,TD)
03220      5 CONTINUE
03230      DO 10 I=1,N
03240      DO 10 J=1,N
03250      II(I,J)=0.
03260      IF(I.EQ.J)II(I,J)=1.
03270      10 CONTINUE
03280      CALL SCARAT(LAMR,II,C,N,N)
03290      DO 20 I=1,N
03300      DO 20 J=1,N
03310      YB(I,J)=C(I,J)-A(I,J)
03320      YB(I+N,J+N)=YB(I,J)
03330      20 CONTINUE
03340      CALL SCARAT(LAMI,II,C,N,N)
03350      DO 30 I=1,N
03360      DO 30 J=1,N
03370      YB(I,J+N)=-C(I,J)
03380      YB(I+N,J)=C(I,J)
03390      30 CONTINUE
03400      EPS=1.E-10
03410C
03420C      FIND INVERSE(YB)
03430C
03440      CALL MXINVD(YB,N2,N2,DET,IRANK,EPS,OR)
03450      DO 40 I=1,N
03460      DO 40 J=1,2
03470      RB(I,J)=R(I,J)
03480      RB(I+N,J)=0.
03490      RB(I,J+2)=0.
03500      RB(I+N,J+2)=B(I,J)
03510      40 CONTINUE
03520      CALL MATMUL(YB,RB,LB,N2,N2,4)
03530      DO 42 I=1,N2
03540      DO 42 J=1,N2
03550      OR(I,J)=0.
03560      42 CONTINUE
03570      WRITE(6,41)ID
03580      41 FORMAT('X',INPUT REAL PART OF THE DIAGONAL OF THE OR MATRIX FOR
03590+FIGURE VECTOR ',I2,'.')

```

```

03650C
03630 READ(5,4)(OB(J,J),J=1,N)
03640 WRITE(6,43)ID
03650 43 FORMAT('X','INPUT IMAGINARY PART OF THE DIAGONAL OF THE QB MATRIX
03660+FOR EIGENVECTOR ',I2,'.')
03670 READ(5,*)(OB(J+N,J+N),J=1,N)
03680 CALL MATMUL(OB,OB,OB,BB,N2,N2,4)
03690 CALL MATRA(LB,LBT,N2,4)
03700 CALL MATMUL(LBT,BB,R,4,N2,4)
03710C
03720C FIND INVERSE(R)
03730C
03740 CALL MXLNED(R,4,4,DET,JRANK,EPS,RR)
03750 CALL MATMUL(OB,VR,P,N2,N2,1)
03760 CALL MATMUL(LBT,P,T,4,N2,1)
03770 CALL MATMUL(R,T,UR,4,4,1)
03780 CALL MATMUL(LB,UB,VR,N2,4,1)
03790 DO 60 J=1,N
03800 VECRD(I,ID)=VB(I,1)
03810 VECID(I,ID)=VB(I+N,1)
03820 60 CONTINUE
03830 DO 70 I=1,2
03840 UR(I,ID)=UR(I,1)
03850 UI(I,ID)=UR(I+2,1)
03860 70 CONTINUE
03870 RETURN
03880 END
03890C
03900C
03910 SUBROUTINE PROG4(ID,ERD,UR,VECRD,A,B,N,NM2,NM1,OB,LB,YB,
03920+BB,II,LBT,VB,PP,C,P,DV)
03930C
03940C THIS ROUTINE DETERMINES THE CLOSED LOOP ATTAINABLE
03950C EIGENVECTORS FOR THE UNCONTROLLABLE GUST MODES
03960C
03970 DIMENSION ERD(N),UR(2,N),VECRD(N,N),A(N,N),B(N,N),OB(NM2,
03980+NM2),UB(2,1),VB(NM2,1),YB(NM2,NM2),BB(NM2,2),C(N,N),R(2,2),
03990+PP(NM2,1),T(2,1),RR(2,2),PC(NM2,2),VD(2,1),DV(NM2,1)
04000 REAL TI(N,N),LB(NM2,2),LBT(2,NM2),LAMU
04010 LAMB=ERD(ID)
04020 DO 5 J=1,NM2
04030 VB(I,1)=VECRD(I,ID)
04040 5 CONTINUE
04050 VD(1,1)=VECRD(NM1,ID)
04060 VD(2,1)=VECRD(N,ID)
04070 DO 10 I=1,N
04080 DO 10 J=1,N
04090 TI(I,J)=0.
04100 IF(T,ERD,J)TI(I,1)=1.

```

```

00 20 I=1,NM2
P(I,1)=C(I,NM1)-A(I,NM1)
P(I,2)=C(I,N)-A(I,N)
00 20 J=1,NM2
YR(I,J)=C(I,J)-A(I,J)
20 CONTINUE
EPS=1.E-10

FIND INVERSE(YB)

CALL MXLNED(YB,NM2,NM2,DET,
00 40 I=1,NM2
00 40 J=1,2
BB(I,J)=B(I,J)
40 CONTINUE
CALL MATHUL(YB,P,LB,NM2,NM2,NM2)
CALL MATHUL(LB,VD,DV,NM2,2,
CALL MATHUL(YB,RR,LR,NM2,NM2,NM2)
CALL MATADD(VB,DV,VB,NM2,1
00 42 I=1,NM2
00 42 J=1,NM2
0B(I,J)=0.
42 CONTINUE
WRITE(6,41)ID
41 FORMAT('X','INPUT REAL PART
04380+EIGENVECTOR ',I2,')
READ(5,*)(0B(J,J),J=1,NM2)
CALL MATHUL(0B,LB,BB,NM2,NM2,NM2)
CALL MATTRA(LB,LRT,NM2,2)
CALL MATHUL(LRT,BB,R,2,NM2,
04430F
FIND INVERSE(R)
)
CALL MXLNED(R,2,2,DET,IRAN
CALL MATHUL(0B,VB,PP,NM2,NM2,NM2)
CALL MATHUL(LRT,PP,T,2,NM2)
CALL MATHUL(R,T,VB,2,2,1)
CALL MATHUL(LB,VB,VB,NM2,2,
CALL SCMAT(-1.,DV,DV,NM2,
CALL MATADD(VB,DV,VB,NM2,1
00 60 I=1,NM2
VECR(I,ID)=VB(I,1)
60 CONTINUE
00 70 I=1,2
WR(J,ID)=WB(I,1)
70 CONTINUE
RETURN
END

```



```

82/12/15
NNFTS  PROGRAM  COV
00100  PROGRAM COV(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT,FILE3,
00110+TAPE1=FILE3,GAINS,TAPE3=GAINS,TAPE2)
00120C+++++*****
00130C THIS PROGRAM INPUTS THE STATE MATRICES
00140C (OUTPUT OF FLUTTER) A, B, W, FEEDBACK
00150C GAINS(OUTPUT OF MODAL), INTENSITY OF THE
00160C GUST NOISE AND OUTPUTS THE CLOSED LOOP
00170C STATE COVARIANCE MATRIX, RMS CONTROL SURFACE
00180C RATES AND DEFLECTIONS IN DEGREES.(NOTE: INPUT
00190C ZERO FEEDBACK GAINS FOR OPEN LOOP RESULTS)
00200C*****
00210  DIMENSION A(42,42),W(2,42),Z(42,42),
00220+FU1(42),VECD(42,42),VECD(42,42),W(42,1),
00230+8(42,2)
00240  WRITE(6,10)
00250  10 FORMAT(1X,'INPUT ORDER OF SYSTEM')
00260  READ(5,*)N
00270  CALL PROG1(N,A,WI,Z,FU1,VECD,VECD,
00280+W,B)
00290  STOP
00300  END
00310C
00320C
00330  SUBROUTINE PROG1(N,A,WI,Z,FU1,VECD,VECD,
00340+W,B)
00350  DIMENSION A(N,N),WI(2,N),Z(N,N),FU1(N),
00360+VECD(N,N),VECD(N,N),W(N,1),B(N,2)
00370  DIMENSION PP(42,42),DD(42,42),W(1,42)
00380  REAL JJ(42,42)
00390  CALL GETPF(5HTAPE1,5HFILE3,0,0)
00400C
00410C
00420C
00430  DO 13 I=1,N
00440  READ(1,15)W(I,1)
00450  15 FORMAT(3E16.8)
00460  13 CONTINUE
00470  DO 16 I=1,N
00480  DO 16 J=1,N
00490  READ(1,15)A(I,J)
00500  16 CONTINUE
00510  DO 17 I=1,N
00520  READ(1,15)R(I,1),B(I,2)
00530  17 CONTINUE

```

READ IN FEEDBACK GAINS OUTPUT FROM PROGRAM: MANUAL

```

00560C
00570C
00580
00590
00600
00610
00620
00630
00640
00650
00660C
00670C
00680C.....T(M,P)=A(M,N) * U(N,P)
00690 SUBROUTINE MATMUL(A,U,T,M,N,P)
00700 INTEGER P
00710 DIMENSION A(M,N),U(N,P),T(M,P)
00720 DO 1 I=1,M
00730 DO 1 J=1,P
00740 T(I,J)=0.
00750 1 CONTINUE
00760 DO 2 I=1,M
00770 DO 2 J=1,P
00780 DO 2 K=1,N
00790 T(I,J)=A(I,K)*U(K,J)+T(I,J)
00800 2 CONTINUE
00810 RETURN
00820 END
00830C
00840C
00850C.....C(M,N)=A(M,N) + B(M,N)
00860 SUBROUTINE MATADD(A,B,C,M,N)
00870 DIMENSION A(M,N),B(M,N),C(M,N)
00880 DO 3 I=1,M
00890 DO 3 J=1,N
00900 C(I,J)=A(I,J)+B(I,J)
00910 3 CONTINUE
00920 RETURN
00930 END
00940C
00950C
00960C.....B(M,N)=S * A(M,N)
00970 SUBROUTINE SCMAT(S,A,B,M,N)
00980 DIMENSION A(M,N),B(M,N)
00990 DO 8 I=1,M
01000 DO 8 J=1,N
01010 B(I,J)=S*A(I,J)
01020 8 CONTINUE
01030 RETURN
01040 END

```

```

01070C.....V(N,M)=A(M,N) TRANPOSED
01080 SUBROUTINE MATTRA(A,V,M,N)
01090 DIMENSION A(M,N),V(N,M)
01100 DO 14 I=1,M
01110 DO 14 J=1,N
01120 V(J,I)=A(I,J)
01130 14 CONTINUE
01140 RETURN
01150 END

01160C
01170C
01180C

01190 SUBROUTINE PROG4(N,A,X,Q,XN,F,P,DX,WA,D,DT)
01200 DIMENSION A(N,N),X(N,N),Q(N,N),XN(N,N),E(N,N),P(N,N),DX(N,N),
01210+WA(N),D(N,1),DT(1,N)
01220 WRITE(6,10)
01230 10 FORMAT(1X,'INPUT THE INTENSITY OF THE GUST NOISE, R.')
01240 READ(5,*)R
01250 CALL MATTRA(D,DT,N,1)
01260 CALL SCAMAT(R,D,D,N,1)
01270 CALL MATMUL(D,DT,D,N,1,N)
01280 CALL CAL(A,Q,XN,M,15,2,X,E,P,DX,WA)
01290 WRITE(6,35)
01300 NN=N-9
01310 ZZ=57.3*SQRT(XN(NN+1,NN+1))
01320 WRITE(6,38)ZZ
01330 77=57.3*SQRT(XN(NN+2,NN+2))
01340 WRITE(6,39)Z7
01350 7Z=57.3*SQRT(XN(NN+4,NN+4))
01360 WRITE(6,40)ZZ
01370 ZZ=57.3*SQRT(XN(NN+5,NN+5))
01380 WRITE(6,41)ZZ
01390 38 FORMAT(1X,'OUTBOARD DEFLECTION =',E15.4)
01400 39 FORMAT(1X,'OUTBOARD RATE =',E15.4)
01410 40 FORMAT(1X,'INBOARD DEFLECTION =',E15.4)
01420 41 FORMAT(1X,'INBOARD RATE =',E15.4)
01430 35 FORMAT(1X,'RMS OF CONTROL RESPONSE'//)
01440 DO 24 I=1,N
01450 DO 24 J=1,N
01460 WRITE(2,164)XN(I,J)
01470 164 FORMAT(E16.8)
01480 24 CONTINUE
01490 CALL REPLACE(5HTAPE2,5HCOUST,0,0)
01500 RETURN
01510 END

01520C
01530C
01540 SUBROUTINE CAL(A,Q,XN,N,IMAX,IT,X,E,P,DX,WA)
01550C

```

```

01580 DIMENSION A(N,N),D(N,N),XN(N,N)
01590 DIMENSION X(N,N),E(N,N),P(N,N),DX(N,N),UA(N)
01600 TR=0.
01610 DO 300 I=1,N
01620 300 TR=TR+A(I,I)
01630 FN=N
01640 IF (TR) 301,302,301
01650 301 ALF=ABS(TR)/FN
01660 GO TO 303
01670 302 ALF=1.
01680 303 CONTINUE
01690 EE=.01
01700 NC=N*(N+1)
01710 NC=NC/2
01720 DO 60 I=1,N
01730 DO 63 J=1,N
01740 GO TO (61,62),TT
01750 61 P(I,J)=A(I,J)
01760 X(I,J)=A(I,J)
01770 GO TO 63
01780 62 P(I,J)=A(J,I)
01790 X(I,J)=A(J,I)
01800 63 CONTINUE
01810 P(I,I)=P(I,I)-ALF
01820 X(I,I)=X(I,I)-ALF
01830 60 CONTINUE
01840C
01850C
01860C
01870 CALL MXLNER(P,N,N,DET,N,1.E-14,UA)
01880 DO 4 I=1,N
01890 DO 4 J=1,N
01900 E(I,J)=0.
01910 DO 4 K=1,N
01920 4 E(I,J)=E(I,J)+P(K,I)*D(K,J)*2.*ALF
01930 DO 5 I=1,N
01940 DO 5 J=1,N
01950 XN(I,J)=0.
01960 DO 5 K=1,N
01970 5 XN(I,J)=XN(I,J)+E(I,K)*P(K,I)
01980 DO 7 I=1,N
01990 DO 8 J=1,N
02000 8 P(I,J)=P(I,J)+2.*ALF
02010 7 P(I,J)=P(I,J)+1.
02020 ITER=0
02030 100 CONTINUE
02040 DO 9 I=1,N
02050 DO 9 J=1,N
02060 E(I,J)=0.

```

```

02080 Y E(I,J)=E(I,J)+P(K,J)*XN(K,J)
02090 DO 10 I=1,N
02100 DO 10 J=1,N
02110 DX(I,J)=0.
02120 DO 10 K=1,N
02130 DX(I,J)=DX(I,J)+E(I,K)*P(K,J)
02140 DO 20 I=1,N
02150 DO 20 J=1,N
02160 F(I,J)=P(I,J)
02170 X(I,J)=P(I,J)
02180 DO 12 I=1,N
02190 DO 12 J=1,N
02200 XN(I,J)=XN(I,J)+DX(I,J)
02210 XN(J,I)=XN(I,J)
02220 ICOT=0
02230 DO 15 I=1,N
02240 DO 15 J=1,N
02250 IF(XN(I,J))201,14,201
02260 201 RAT=ABS(DX(I,J))/XN(I,J)
02270 IF(RAT-EE)14,14,70
02280 14 ICOT=ICOT+1
02290 15 CONTINUE
02300 70 CONTINUE
02310 IF(ICOT-NC)16,18,16
02320 16 DO 17 I=1,N
02330 DO 17 J=1,N
02340 P(I,J)=0.
02350 DO 17 K=1,N
02360 P(I,J)=P(I,J)+E(I,K)*X(K,J)
02370 18 ITER=ITER+1
02380 IF(ICOT-NC)40,50,40
02390 40 IF(ITER-IMAX)100,50,50
02400 50 CONTINUE
02410 PRINT 600,ITER
02420 600 FORMAT(10X,'INNER LOOP TERMINATED AT ITER =',(2)
02430 RETURN
02440 END

```

```

R2/12/15
NNFTS      PROGRAM  LOADS

00100      PROGRAM LOADS(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT,COVST,
00110+TAPE3=COVST,LMAT,TAPE2=LMAT)
00120*****
00130C     THIS PROGRAM INPUTS CLOSED LOOP STATE COVARIANCE MATRIX
00140C     (OUTPUT FROM COV), LOADS INFLUENCE MATRIX AND OUTPUTS
00150C     THE RMS SHEAR, RMS BENDING MOMENT, AND RMS TORQUE AT
00160C     * VARIOUS STATIONS ALONG THE WING SPAN.
00170C*****
00180      REAL XN(42,42),T(10,42),LT(9,42),LTT(42,9),TEMP(42,9)
00190      DIMENSION KRET(8)
00200      WRITE(6,10)
00210      10 FORMAT(1X,'INPUT WHICH STATES WERE RETAINED(1) OR DELETED(0)?')
00220      READ(5,*)(KRET(J),J=1,8)
00230      KSUM=0
00240      DO 20 I=1,8
00250          KSUM=KSUM+KRET(I)
00260      20 CONTINUE
00270      WRITE(6,11)
00280      11 FORMAT(1X,'INPUT THE NUMBER OF LAG STATES?')
00290      READ(5,*)M
00300      KST=KSUM*(2+M)
00310      KKSUM=KST+9
00320      CALL PROG1(KST,KKSUM,KRET,XN,T,L,LTT,TEMP)
00330      STOP
00340      END

00350C
00360C
00370      SUBROUTINE PROG1(KST,KKSUM,KRET,XN,T,L,LTT,TEMP)
00380      REAL LBM(9,10),LSH(9,10),LTD(9,10),XN(KKSUM,KKSUM),T(10,KKSUM),
00390+LTD(9,KKSUM),LTT(KKSUM,9),TEMP(KKSUM,9),COV(9,9),BM(9),SH(9),TD(9)
00400      DIMENSION KRET(8)
00410      CALL GETPF(5HTAPE2,4HLMAT,0,0)
00420      DO 10 I=1,10
00430          DO 10 J=1,9
00440C
00450C
00460C
00470      READ(2,15)LBM(J,1),LSH(J,J),LTD(J,J)
00480      15 FORMAT(3E16.8)
00490      10 CONTINUE
00500      CALL GETPF(5HTAPE3,5HCOVST,0,0)
00510      DO 20 I=1,KKSUM
00520          DO 20 J=1,KKSUM

```

```

005500 READ(3,15)XN(I,J)
00560 20 CONTINUE
00570 DO 40 I=1,10
00580 DO 40 J=1,KKSUM
00590 T(I,J)=0.
00600 40 CONTINUE
00610 J=0
00620 DO 50 I=1,8
00630 IF(KKRET(I).EQ.0)GO TO 50
00640 J=J+1
00650 T(I,J)=1.
00660 50 CONTINUE
00670 T(9,KST+1)=.514
00680 T(10,KST+4)=.518
00690 CALL MATMUL(LRN,T,I,T,9,10,KKSUM)
00700 CALL MATTRA(LT,LTT,9,KKSUM)
00710 CALL MATMUL(XN,LTT,TEMP,KKSUM,KKSUM,9)
00720 CALL MATMUL(I,T,TEMP,COV,9,KKSUM,9)
00730 DO 60 I=1,9
00740 BK(I)=SORT(COV(I,I))
00750 60 CONTINUE
00760 CALL MATMUL(LSH,T,LT,9,10,KKSUM)
00770 CALL MATTRA(LT,LTT,9,KKSUM)
00780 CALL MATMUL(XN,LTT,TEMP,KKSUM,KKSUM,9)
00790 CALL MATMUL(LT,TEMP,COV,9,KKSUM,9)
00800 DO 70 I=1,9
00810 SH(I)=SORT(COV(I,I))
00820 70 CONTINUE
00830 CALL MATMUL(I,T,T,LT,9,10,KKSUM)
00840 CALL MATTRA(LT,LTT,9,KKSUM)
00850 CALL MATMUL(XN,LTT,TEMP,KKSUM,KKSUM,9)
00860 CALL MATMUL(LT,TEMP,COV,9,KKSUM,9)
00870 DO 80 I=1,9
00880 TO(I)=SORT(COV(I,I))
00890 80 CONTINUE
00900 WRITE(6,90)
00910 90 FORMAT(35X,'RMS LOADS'/1X,'BEND MOM',27X,'SHEAR',27X,'TORQUE'///)
00920 DO 100 I=1,9
00930 100 FORMAT(5X,E16.4,10X,E16.4,10X,E16.4)
00940 WRITE(6,110)BK(I),SH(I),TO(I)
00950 110 CONTINUE
00960 RETURN
00970 END
00980
00990
01000 SUBROUTINE MATMUL(A,I,T,M,N,P)
01010 INTGFR P
01020 DIMENSION A(M,N),I(N,P),T(M,P)

```

```
01060  DO 1 I=1,P
01070  T(I,J)=0.
01080  1 CONTINUE
01090  DO 2 I=1,M
01100  DO 2 J=1,P
01110  DO 2 K=1,N
01120  T(I,J)=A(I,K)*U(K,J)+T(I,J)
01130  2 CONTINUE
01140  RETURN
01150C  END
01160C
01170  SUBROUTINE MATTRA(A,V,M,N)
01180  DIMENSION A(M,N),V(N,M)
01190  DO 14 I=1,M
01200  DO 14 J=1,N
01210  V(J,I)=A(I,J)
01220  14 CONTINUE
01230  RETURN
01240  END
```


8/2/12/15

INPUTS PROGRAM FEEDBACK

```

00100 PROGRAM FEEDBACK(INPUT,OUTPUT,TAPE5=INPUT,TAPE6=OUTPUT,ONELEF,
00110+TAPE2=ONELEF,MASS,TAPE1=MASS,GAIN1,TAPE3=GAIN1,TAPE4)
00120C*****
00130C THIS PROGRAM INPUTS THE STRUCTURAL MASS,STRUCTURAL STIFFNESS,
00140C STRUCTURAL DAMPING, AERODYNAMIC INFLUENCE MATRICES, FLIGHT
00150C CONDITION, FEEDBACK GAINS(OUTPUT OF MODAL) AND OUTPUTS THE
00160C CLOSED LOOP EIGENVALUES. THIS IS USEFUL TO STUDY OFF DESIGN
00170C PERFORMANCE.
00180C*****
00190 REAL MXX(8,8),CS(8,8),KS(8,8),CT(8,8),KT(8,8),CC(8,8),
00200+KK(8,8),A2X(8,8),A1X(8,8),A0X(8,8),MINV(8,8),A2X0(8,8)
00210+,A1X0(8,8),A0X0(8,8),A1(16,16),A2(32,32),00(8,2),DUM1(8,7),
00220+DUM2(8,7),DUM3(8,2),DUM4(8,7),DUM5(8,2),DUM6(8,2),DUM7(8,1)
00230 REAL DUM8(8,1),A0U(8,2),A1U(8,2),EI(8,2,4),R(8,2),
00240+EI16(8,7,4),FI(8,4),A3(40,40),B1(40,2),B2(32,2),II(8,8),
00250+DI(8,8,4),KT(4),A1D(8,1),A0D(8,1),T(8,1),U(8,1),A4(42,42),
00260+B4(42,2),W(42,1),B1(16,2),A5(24,24),B5(24,2)
00270 WRITE(6,8)
00280 8 FORMAT(1X,'INPUT THE ORDER OF THE STRUCTURAL-RIGID BODY STATE VECTO
00290+R(N)')
00300 READ(5,*)N
00310 WRITE(6,10)
00320 10 FORMAT(1X,'INPUT VELOCITY(V), CHORD(C), DYNAMIC PRESSURE(Q), NUMBE
00330+R OF LAG STATES(L)')
00340C
00350C INPUT FLIGHT CONDITIONS
00360C
00370 READ(5,*)V,C,Q,L
00380 DO 20 I=1,L
00390 WRITE(6,25)I
00400C
00410C INPUT AERODYNAMIC LAG FREQUENCIES
00420C
00430 READ(5,*)KI(I)
00440 20 CONTINUE
00450 25 FORMAT(1X,'INPUT KI('',I1,'')')
00460 N2=?*N
00470 KEND=N*(L+2)
00480 KEND1=KEND+7
00490 KEND2=KEND+2
00500 K5=2*N+7
00510 CALL PRO61(N,N2,KEND,KEND1,K5,V,C,Q,L,MXX,CS,KS,CT,KT,
00520+CC,KK,A2X,A1X,A0X,MINV,A2X0,A1X0,A0X0,A1,A2,00,DUM1,DUM2,DUM3,DUM4
00530+,DUM5,DUM6,DUM7,DUM8,A0U,A1U,EI,R,EI16,IJ,A3,B3,B2,FI,DI,KT,A1D,

```

```

00550 SUBROUTINE PROG1(N,N2,KEND,KENDD,KEND2,K5,V,C,D,L,MXX,CS,KS,CT,KT,
00560 CC,KK,A2X,A1X,A0X,MINU,A2XQ,A1XQ,A0XQ,A1,A2,QD,DUM1,DUM2,DUM3,DUM4
00570 +,DUM5,DUM6,DUM7,DUM8,A0U,A1U,ET,R,ETJG,IT,A3,B3,B2,F1,D1,K1,A1D,
00580 +A0D,T,U,A4,R1,B4,W,A5,B5)
00590 REAL LAMDA,LL
00600 INTEGER FLAG
00610 COMMON KRET(42)
00620 REAL MXX(N,N),CS(N,N),KS(N,N),CT(N,N),KT(N,N),CC(N,N),KK(N,N),
00630 +A2X(N,N),A1X(N,N),A0X(N,N),MINU(N,N),A2XQ(N,N),A1XQ(N,N),A0XQ(N,N),
00640 +A1(N,N),A2(KEND,KEND),QD(N,N),DUM1(N,N),DUM2(N,N),DUM3(N,N),
00650 +DUM4(N,N),DUM5(N,N),DUM6(N,N),DUM7(N,N),DUM8(N,N),A0U(N,N),
00660 +A0D(N,N),A1U(N,N),
00670 +EI(N,N,2,L),G(7,7),H(7,2),R(N,N),JG(2,7),ETJG(N,7,L),FI(N,L),
00680 +JH(2,2),A3(KEND,KEND),B3(KEND,2),B2(KEND,2),II(N,N),DI(N,N,L),
00690 +KI(L),A1B(N,1),A0D(N,1),I(N,1),U(N,1),A4(KEND,KEND),
00700 +B1(N,2),B4(KEND,2),W(KEND,1),
00710 +A5(K5,K5),B5(K5,2),JJ(2,7)
00720 REAL AA(42,42),BB(42,2)
00730 CALL GETPF(5HTAPE1,4HMASS,0,0)
00740 DO 1 I=1,N
00750 DO 1 J=1,N
00760 READ IN STRUCTURAL DATA
00770 READ(1,101)MXX(I,J),CS(I,J),KS(I,J)
00780 1 CONTINUE
00790 DO 3 I=1,7
00800 DO 3 J=1,7
00810 READ IN ACTUATOR DATA
00820 READ(1,101)G(I,J)
00830 3 CONTINUE
00840 DO 4 I=1,7
00850 READ(1,101)(H(I,J),J=1,2)
00860 4 CONTINUE
00870 DO 5 J=1,7
00880 READ(1,101)(JJ(I,J),I=1,2)
00890 5 CONTINUE
00900 CALL GETPF(5HTAPE2,6HONELEE,0,0)
00910 DO 430 K=1,L
00920 DO 410 J=1,N
00930 DO 410 I=1,N
00940 READ IN AERODYNAMIC INFLUENCE DATA
00950
00960
00970
00980
00990
01000
01010
01020
01030
01040

```

```

01070 DO 420 I=1,2
01070 DO 420 I=1,N
01080 READ(2,101)A00(I,1),A10(I,J),E1(I,I,K)
01090 420 CONTINUE
01100 DO 430 I=1,N
01110 READ(2,101)A00(I,K),A10(I,K),FI(I,K)
01120 FI(I,K)=FI(I,K)/V
01130 430 CONTINUE
01140 101 FORMAT(3E16.8)
01150 109 FORMAT(4E16.8)
01160 EPS=1.E-10
01170 TEMP=0*(C/2./V)**2
01180 TEMP2=0+C/2./V
01190 CALL SCAMAT(TEMP,A2X,A2X0,N,N)
01200 CALL MATADD(MXX,A2X0,MJNV,N,N)
01210 FIND INVERSE(MJNV)
01220C
01230C
01240C
01250 CALL MXLNEQ(MJNV,N,N,DET,JRANK,EPS,A2X0,0)
01260 CALL SCAMAT(TEMP2,A1X,A1X0,N,N)
01270 CALL MATADD(CS,A1X0,CT,N,N)
01280 CALL SCAMAT(0,A0X,A0X0,N,N)
01290 CALL MATADD(KS,A0X0,KT,N,N)
01300 CALL SCAMAT(-1.,MINV,MINV,N,N)
01310 CALL MATMUL(MJNV,KT,KK,N,N,N)
01320 CALL MATMUL(MJNV,CT,CC,N,N,N)
01330 DO 15 I=1,N
01340 DO 14 J=1,N
01350 TI(I,J)=0.
01360 14 CONTINUE
01370 TI(I,I)=1.0
01380 15 CONTINUE
01390 N21=N2+1
01400 DO 18 I=1,N
01410 DO 18 J=1,N
01420 A1(I,J)=0.
01430 A1(I,J+N)=TI(I,J)
01440 A1(I+N,J)=KK(I,J)
01450 A1(I+N,J+N)=CC(I,J)
01460 18 CONTINUE
01470 IF(1.E0,0)GO TO 102
01480 DO 20 I=1,KEND
01490 DO 20 J=1,KEND
01500 A2(I,J)=0.
01510 20 CONTINUE
01520 DO 25 I=1,N
01530 DO 25 J=1,N
01540 A2(I,J)=A1(I,J)
01550 A2(I+6,J)=A1(I+N,I)

```

```
01580      DO 25 K=1,L
01590      KN=K+N
01600      A2(T+N,KN+N+J)=MINV(I,J)
01610      A2(KN+N+I,J+N)=DI(I,J,K)
01620      A2(KN+N+I,KN+N+I)=-2.*U*(I(K)/C
01630 25 CONTINUE
01640      SCA=0*C/2./U
01650      CALL SCAMAT(SCA,A11,00,N,2)
01660      CALL SCAMAT(0,A0U,R,N,2)
01670      DO 36 I=1,KEND0
01680      DO 36 J=1,KEND0
01690      A3(I,J)=0.
01700 36 CONTINUE
01710      DO 37 I=1,KEND
01720      DO 37 J=1,KEND
01730      A3(I,J)=A2(I,J)
01740 37 CONTINUE
01750      DO 38 I=1,7
01760      DO 38 J=1,7
01770      A3(KEND+I,KEND+J)=6(I,J)
01780 38 CONTINUE
01790      CALL MATMUL(JJ,6,J6,2,7,7)
01800      CALL MATMUL(O0,J6,DUM1,N,2,7)
01810      CALL MATMUL(R,JJ,DUM2,N,2,7)
01820      CALL MATADD(DUM2,DUM1,DUM2,N,7)
01830      CALL MATMUL(MINV,DUM2,DUM1,N,N,7)
01840      DO 40 K=1,L
01850      DO 39 I=1,N
01860      DO 39 J=1,2
01870      DUM3(I,J)=EI(I,J,K)
01880 39 CONTINUE
01890      CALL MATMUL(DUM3,J6,DUM4,N,2,7)
01900      DO 40 I=1,N
01910      DO 40 J=1,7
01920      EI(J(I,J,K)=DUM4(I,J)
01930 40 CONTINUE
01940      DO 45 I=1,N
01950      DO 45 J=1,7
01960      A3(I+N,J+KEND)=DUM1(I,I)
01970      DO 45 K=1,L
01980      KN=K+N
01990      A3(KN+N+I,J+KEND)=EI(J(I,I,K)
02000 45 CONTINUE
02010      CALL MATMUL(JJ,H,JH,2,7,2)
02020      CALL MATMUL(O0,JH,DUM3,N,2,2)
02030      CALL MATMUL(MINV,DUM3,DUM5,N,N,2)
02040      DO 47 K=1,L
02050      DO 46 I=1,N
02060      DO 46 J=1,2
```

```

02090 CALL MATMUL(DUM3,JH,DUM6,N,2,2)
02100 DO 47 I=1,N
02110 DO 47 J=1,2
02120 EIG(I,K)=DUM6(I,J)
02130 47 CONTINUE
02140 DO 48 I=1,N
02150 DO 48 J=1,2
02160 R3(I,J)=0.
02170 R3(I+N,J)=DUM5(I,J)
02180 DO 48 K=1,L
02190 KN=K*N
02200 R3(I+KN+N,J)=EIG(I,J,K)
02210 48 CONTINUE
02220 DO 49 I=1,7
02230 DO 49 J=1,2
02240 R3(I+KEND,J)=H(I,J)
02250 49 CONTINUE
02260 WRITE(6,56)
02270 56 FORMAT(1X,'INPUT CHARACTERISTIC LENGTH(LL) OF NOISE//')
02280 READ(5,*)LL
02290 TEMP3=TEMP2/V
02300 CALL SCAMAT(TEMP3,A1D,I,N,1)
02310 Q1=D/V
02320 CALL SCAMAT(Q1,A0D,U,N,1)
02330 CALL MATMUL(MINV,U,DUM7,N,N,1)
02340 CALL MATMUL(MINV,T,DUM8,N,N,1)
02350 DO 58 I=1,KEND
02360 DO 58 J=1,2
02370 R4(I,J)=R3(I,J)
02380 R4(KEND+1,J)=0.
02390 R4(KEND+2,J)=0.
02400 58 CONTINUE
02410 DO 59 I=1,KEND
02420 DO 59 J=1,KEND
02430 A4(I,J)=0.
02440 59 CONTINUE
02450 DO 60 I=1,KEND
02460 DO 60 J=1,KEND
02470 A4(I,J)=A3(I,J)
02480 60 CONTINUE
02490 A4(KEND+1,KEND+2)=1.
02500 A4(KEND+2,KEND+1)=-1.001*(U/LL)*#2
02510 A4(KEND+2,KEND+2)=-2.001*U/LL
02520 DO 62 I=1,N
02530 A4(I+N,KEND+1)=DUM7(I,1)
02540 A4(I+N,KEND+2)=DUM8(I,1)
02550 DO 62 K=1,L
02560 KN=K*N
02570 A4(I+KN+N,KEND+2)=EIG(I,K)

```

```

02600 W(J,1)=0.
02610 64 CONTINUE
02620 XX=1.732*V/LL
02630 W(KEND0+1,1)=XX
02640 W(KEND0+2,1)=-2.464*(V/LL)*#2
02650 CALL SCAMAT(XX,DUM8,DUM8,N,1)
02660 DO 66 J=1,N
02670 W(I+N,1)=DUM8(I,1)
02680 DO 66 K=1,L
02690 KN=K*N
02700 W(I+N+KN,1)=XX*F(I,K)
02710 66 CONTINUE
02720 FLAG=4
02730 GO TO 200
02740 102 SCA=0.6/2./U
02750 CALL SCAMAT(SCA,AIU,00,N,2)
02760 CALL SCAMAT(0,AOU,R,N,2)
02770 DO 106 I=1,K5
02780 DO 106 J=1,K5
02790 A5(I,J)=0.
02800 106 CONTINUE
02810 CALL MATMUL(JJ,H,JH,2,2,2)
02820 CALL MATMUL(OO,JH,DUM3,N,2,2)
02830 CALL MATMUL(MINV,DUM3,DUM5,N,N,2)
02840 DO 108 I=1,N
02850 DO 108 J=1,2
02860 B5(I,J)=0.
02870 B5(I+N,J)=DUM5(I,J)
02880 108 CONTINUE
02890 DO 110 I=1,7
02900 DO 110 J=1,2
02910 B5(I+N2,J)=H(I,J)
02920 110 CONTINUE
02930 DO 112 I=1,N2
02940 DO 112 J=1,N2
02950 A5(I,J)=A1(I,J)
02960 112 CONTINUE
02970 CALL MATMUL(JJ,G,JG,2,2,2)
02980 CALL MATMUL(OO,JG,DUM1,N,2,2)
02990 CALL MATMUL(R,JJ,DUM2,N,2,2)
03000 CALL MATMUL(DUM2,DUM1,DUM2,N,2)
03010 CALL MATMUL(MINV,DUM2,DUM1,N,N,2)
03020 DO 114 I=1,N
03030 DO 114 J=1,7
03040 A5(I+N,J+N2)=DUM1(I,J)
03050 114 CONTINUE
03060 DO 116 I=1,7
03070 DO 116 J=1,7
03080 A5(I+N2,J+N2)=G(I,J)

```

```

03110 200 WRITE(6,201)
03120 201 FORMAT(1X,'INPUT RETAIN(I) OR DELETE(I) FOR EACH STATE MEMBER'/)
03130 KSTATE=N
03140 KSUM=0
03150 READ(5,*)(KRET(J),J=1,KSTATE)
03160 DO 205 I=1,KSTATE
03170 KRET(I+N)=KRET(I)
03180 IF(KRET(I).EQ.1)KSUM=KSUM+1
03190 205 CONTINUE
03200 IF(L.EQ.0)GO TO 207
03210 DO 206 K=1,L
03220 DO 206 I=1,N
03230 KN=N*(K+1)+I
03240 KRET(KN)=KRET(I)
03250 206 CONTINUE
03260 DO 209 I=1,9
03270 KRET(KEND+I)=1
03280 209 CONTINUE
03290 207 GO TO(310,320,330,340,350),FLAG
03300 310 KSUM=2*KSUM
03310 CALL PR062(FLAG,KSUM,A1,B1,N2,AA,BB)
03320 GO TO 900
03330 320 KSUM=(L+2)*KSUM
03340 CALL PR062(FLAG,KSUM,A2,B2,KEND,AA,BB)
03350 GO TO 900
03360 330 KSUM=7+(L+2)*KSUM
03370 CALL PR062(FLAG,KSUM,A3,B3,KEND,AA,BB)
03380 GO TO 900
03390 340 KSUM=9+(L+2)*KSUM
03400 CALL PR062(FLAG,KSUM,A4,B4,KEND,AA,BB)
03410 GO TO 900
03420 350 KSUM=7+2*KSUM
03430 DO 351 I=N21,K5
03440 KRET(I)=1
03450 351 CONTINUE
03460 CALL PR062(FLAG,KSUM,A5,B5,K5,AA,BB)
03470 900 RETURN
03480 END
03490C
03500C
03510C
03520C
03530C
03540C
03550C
03560C
03570C
03580C
03590C
SUBROUTINE MATDEL(A,N,AA,KSUM)
THIS ROUTINE DELETES DESIRED STATES FROM THE A MATRIX
DIMENSION A(N,N),AA(KSUM,KSUM),JRET(40)
COMMON KRET(42)
I=0
DO 100 I=1,N
IF(KRET(I).EQ.0)GO TO 100

```

```

03620 100 CONTINUE
03630 DO 200 I=1,KSUM
03640 DO 200 J=1,KSUM
03650 AA(I,J)=A(JRET(I),JRET(J))
03660 200 CONTINUE
03670 RETURN
03680 END

03690C
03700C
03710
03720C
03730C
03740C
03750
03760
03770
03780
03790
03800
03810
03820
03830
03840
03850
03860
03870
03880
03890C
03900C
03910C.....T(M,P)=A(M,N) * U(N,P)
03920 SUBROUTINE MATMUL(A,U,T,M,N,P)
03930 INTEGER P
03940 DIMENSION A(M,N),U(N,P),T(M,P)
03950 DO 1 T=1,M
03960 DO 1 J=1,P
03970 T(I,J)=0.
03980 1 CONTINUE
03990 DO 2 T=1,M
04000 DO 2 J=1,P
04010 DO 2 K=1,N
04020 T(I,J)=A(T,K)*U(K,J)+T(I,J)
04030 2 CONTINUE
04040 RETURN
04050 END

04060C
04070C
04080C.....C(M,N)=A(M,N) + B(M,N)
04090 SUBROUTINE MATADD(A,B,C,M,N)
04100 DIMENSION A(M,N),B(M,N),C(M,N)

```

THIS ROUTINE DELETES DESIRED STATES FROM THE R MATRIX(X

SUBROUTINE MATDEL(B,N,BB,KSUM)

DIMENSION B(N,2),BB(KSUM,2),JRET(40)

COMMON KRET(42)

J=0

DO 100 I=1,N

IF(KRET(I).EQ.0)GO TO 100

J=J+1

JRET(J)=I

100 CONTINUE

DO 200 I=1,KSUM

DO 200 J=1,2

BB(I,J)=B(JRET(I),J)

200 CONTINUE

RETURN

END

03900C

03910C.....T(M,P)=A(M,N) * U(N,P)

03920 SUBROUTINE MATMUL(A,U,T,M,N,P)

03930 INTEGER P

03940 DIMENSION A(M,N),U(N,P),T(M,P)

03950 DO 1 T=1,M

03960 DO 1 J=1,P

03970 T(I,J)=0.

03980 1 CONTINUE

03990 DO 2 T=1,M

04000 DO 2 J=1,P

04010 DO 2 K=1,N

04020 T(I,J)=A(T,K)*U(K,J)+T(I,J)

04030 2 CONTINUE

04040 RETURN

04050 END

04060C

04070C

04080C.....C(M,N)=A(M,N) + B(M,N)

04090 SUBROUTINE MATADD(A,B,C,M,N)

04100 DIMENSION A(M,N),B(M,N),C(M,N)


```

04130 C(I,J)=A(I,J)+B(J,I)
04140 3 CONTINUE
04150 RETURN
04160 END
04170C
04180C
04190C.....B(N,N)=S * A(N,N)
04200 SUBROUTINE SCAMAT(S,A,B,M,N)
04210 DIMENSION A(N,N),B(M,N)
04220 DO 8 I=1,M
04230 DO 8 J=1,N
04240 R(I,J)=S*A(I,J)
04250 8 CONTINUE
04260 RETURN
04270 END
04280C
04290C
04300C.....V(N,M)= A(N,N) TRANSPOSED
04310 SUBROUTINE MATTRA(A,V,M,N)
04320 DIMENSION A(N,N),V(N,M)
04330 DO 14 I=1,M
04340 DO 14 J=1,N
04350 V(J,I)=A(I,J)
04360 14 CONTINUE
04370 RETURN
04380 END
04390C
04400C
04410 SUBROUTINE PRO62(FLAG,KSUM,A,B,IP,AA,BB)
04420 INTEGER FLAG,IV1(42)
04430 REAL AA(KSUM,KSUM),BB(KSUM,2),A(IP,IP),R(IP,2),FU1(42)
04440 REAL UR(42),UI(42),Z(42,42),G(2,42)
04450 GO TO(310,320,330,340,350),FLAG
04460 100 FORMAT(3E16.8)
04470 310 CALL MATDEL(A,IP,AA,KSUM)
04480 DO 311 I=1,KSUM
04490 DO 311 J=1,KSUM
04500 WRITE(4,100)AA(I,J)
04510 311 CONTINUE
04520 CALL PRO63(KSUM,AA,UR,UI,Z,IV1,FU1,BB,G)
04530 GO TO 900
04540 320 CALL MATDEL(A,IP,AA,KSUM)
04550 DO 321 I=1,KSUM
04560 DO 321 J=1,KSUM
04570 WRITE(4,100)AA(I,J)
04580 321 CONTINUE
04590 CALL PRO63(KSUM,AA,UR,UI,Z,IV1,FU1,BB,G)
04600 GO TO 900
04610 330 CALL MATDEL(A,IP,AA,KSUM)

```

```

04650      DO 331 J=1,KSUM
04660      WRITE(4,100)AA(I,J)
04670      331 CONTINUE
04680      DO 332 I=1,KSUM
04690      WRITE(4,100)BB(I,1),BB(I,2)
04700      332 CONTINUE
04710      CALL PROG3(KSUM,AA,UR,UI,Z,IV1,FV1,RR,6)
04720      GO TO 900
04730      340 CALL MATREL(A,IP,AA,KSUM)
04740      CALL MATDEL(B,IP,RR,KSUM)
04750      DO 341 I=1,KSUM
04760      DO 341 J=1,KSUM
04770      WRITE(4,100)AA(I,J)
04780      341 CONTINUE
04790      DO 342 I=1,KSUM
04800      WRITE(4,100)BB(I,1),BB(I,2)
04810      342 CONTINUE
04820      CALL PROG3(KSUM,AA,UR,UI,Z,IV1,FV1,RR,6)
04830      GO TO 900
04840      350 CALL MATDEL(A,IP,AA,KSUM)
04850      CALL MATDEL(B,IP,RR,KSUM)
04860      DO 351 I=1,KSUM
04870      DO 351 J=1,KSUM
04880      WRITE(4,100)AA(I,J)
04890      351 CONTINUE
04900      DO 352 I=1,KSUM
04910      WRITE(4,100)BB(I,1),BB(I,2)
04920      352 CONTINUE
04930      CALL PROG3(KSUM,AA,UR,UI,Z,IV1,FV1,RR,6)
04940      900 RETURN
04950      END
04960
04970      SURROUTINE PROG3(N,AA,UR,UI,Z,IV1,FV1,RR,G)
04980      COMMON KRET(42)
04990      DIMENSION AA(N,N),UR(N),UI(N),Z(N,N),IV1(N),FV1(N),6(2,N),BB(N,2)
05000
05010      READ IN FEEDBACK GAINS OUTPUT FROM PROGRAM: MODAL
05020
05030      CALL GETPF(5HTAPE3,5HGAINL,0,0)
05040      DO 24 I=1,N
05050      READ(7,*)(G(J,I),J=1,2)
05060      24 CONTINUE
05070      CALL MATMUL(BB,6,Z,N,2,N)
05080      CALL MATADD(AA,Z,AA,N,N)
05090
05100      CALCULATE CLOSED LOOP EIGENVALUES
05110
05120      CALL RG(N,N,AA,UR,UI,1,7,IV1,FV1,IFRR)

```

```
05150+ IMAGINARY PART')
05160 DO 30 I=1,N
05170 WRITE(6,25)I,WR(I),WI(I)
05180 25 FORMAT(20X,I2,' ',2X,E15.4,15X,E15.4)
05190 30 CONTINUE
05200 RETURN
05210 END
```